







































































Original	Replacement	Original	Replacement
 Power	 Power	 1	 1
 Source	 AV	 2	 2
 P+	 Ch +	 3	 3
 P-	 Ch -	 4	 4
 Vol+	 Vol +	 5	 5
 Vol-	 Vol -	 6	 6
 I-II/Audio	 Dual	 7	 7
 Mute	 Mute	 8	 8
 OK	 Ok	 9	 9
 Up	 Up	 0	 0
 Down	 Down	 List/+10	 List
 Right	 Right	 Back/Program	 Back
 Left	 Left	 Tv/Radio	 TV/R
 Text	 Text	 FAV	 Pre Ch
 Sleep	 Sleep	 EPG	 Guide
 Tv Menu	 Menu	 Setup	 Options
 Exit	 Exit	 DVD Menu	 D. Menu



