







































































Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV
	-/--		Guide
	P +		Ch +
	P -		Ch -
	V +		Vol +
	V -		Vol -
	Mute		Mute
	TV		TV/R
	Back		Back
	Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	I-II		Dual
	Text		Text
	i		Info
	Play / Pause		Play
	Play / Pause		Pause
	Stop		Stop
	Rec		Rec
	Red		Red





	Original	Replacement		Original	Replacement
	Green				
	Yellow				
	Blue				

