










































Original		Replacement		Original		Replacement	
	Power		Power		Info		Info
	Source		AV		Vol +		Vol +
	1		1		Vol -		Vol -
	2		2		Mute		Mute
	3		3		CH +		Ch +
	4		4		CH -		Ch -
	5		5		Exit		Exit
	6		6		Menu		Menu
	7		7		Up		Up
	8		8		Down		Down
	9		9		Right		Right
	0		0		Left		Left
	CH. List		Smart		OK		Ok
	Back		Back		TV / Radio		TV/R
	P.Mode		Format		FAV		Pre Ch
	S.Mode		Dual		Text		Text
	Sleep		Sleep		Audio		Shift + Dual





Original		Replacement	
	EPG		Guide
	Sub.T		Subt
	Reveal		3D
	Hold		Options
	Index		Media
	Sub.PG	+	Shift + Subt
	Rec		Rec
	Stop		Stop
	Play / Pause		Play
	Play / Pause		Pause
	Size		Eject
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
	Red		Red
	Green		Green

Original		Replacement	
	Yellow		Yellow
	Blue		Blue

