






































































Original		Replacement		Original		Replacement	
	Power		Power		EPG		Shift + Guide
	Mute		Mute		Up		Up
	1		1		Down		Down
	2		2		Right		Right
	3		3		Left		Left
	4		4		Enter		Ok
	5		5		CH+		Ch +
	6		6		CH-		Ch -
	7		7		FAV+		Shift + Ch +
	8		8		FAV-		Shift + Ch -
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	-/--		Guide		Sleep		Sleep
	Recall		Back		P.Mode		Shift + Format
	Menu		Menu		S.Mode		Shift + Dual
	Exit		Exit		FAV		Pre Ch
	Tv/AV		AV		Display		Info



