







































































Original	Replacement	Original	Replacement
 Power	 Power	 P +	 CH+ / Page+
 1	 1	 P -	 CH- / Page-
 2	 2	 Menu / DVD	 Menu / Home
 3	 3	 Exit / Back	 Exit / Cancel / Clear
 4	 4	 Up	 Up
 5	 5	 Down	 Down
 6	 6	 Left	 Left
 7	 7	 Right	 Right
 8	 8	 OK	 OK
 9	 9	 Guide / Top Menu	 D.Menu / Top
 0	 0	 Guide / Top Menu	 Shift + D.Menu / Top Menu
 DVD RTN	 Shift + 2	 TV Fav/Radio / Setup	 TV/Radio /
 Input	 AV / Input / RDS	 TV Fav/Radio / Setup	 Shift + TV/Radio / Program
 Audio A/D	 Audio / Lang I/II	 Red	 Red / Netflix / Search
 Mute	 Mute / Dimmer	 Green	 Green / APP / Repeat
 Vol +	 Vol+	 Yellow	 Yellow / YouTube / Repeat
 Vol -	 Vol-	 Blue	 Blue / Prime Video / Random









































































Original	Replacement
Video Format	Shift + 4
Aspect	Picture / Format
Index i+	Info / Angle
Text / Mix	Text / Goto
Open/Close / Subtitle	Eject / Surround
Open/Close / Subtitle	Shift + Eject / Surround
Stop / Dual I/II	Stop / Hold
Stop / Dual I/II	Shift + Stop /
Play	Play / Slow
Pause / Step / [▼]	Pause / Step / Freeze
I<< / Reveal	I<< / Preset-
<< / Hold	Shift + << /
<< / Hold	<< / Tune-
>> / Size	Shift + >> /
>> / Size	>> / Tune+
>>I / Cancel	Shift + >>I / Preset+
>>I / Cancel	>>I / Preset+

Original	Replacement





Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Input		AV / Input / RDS
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	Menu/DVD		Menu / Home
	Exit / Back		Exit / Cancel / Clear
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Top Menu		D.Menu / Top
	Down		Down
	Set Up		Setup / OPT /
	[<>]		Picture / Format
	→ / ←		Display / Media
	[i+]/[≡i]		Info / Angle
	Text/Audio		Text / Goto
	Open/Close/Subtit		Eject / Surround
	Stop/O		Stop / Hold
	Play/[≡o]		Play / Slow
	Pause/Step/[▽]		Pause / Step / Freeze
	I<</[≡?]		I<< / Preset-
	<</[≡+]		<< / Tune-





Original	Replacement	Original	Replacement
	>>/[◆]		
	>>I/[O]/[≡x]		

