

































































Original	Replacement	Original	Replacement
 System Standby	 Power	 Music	 Blue
 Muting	 Mute	 Master Vol +	 Vol +
 Menu	 Menu	 Master Vol -	 Vol -
 1	 1	 >>I / Preset +	 >>I
 2	 2	 I<< / Preset -	 I<<
 3	 3	 Up	 Up
 4	 4	 Left	 Left
 5	 5	 OK	 Ok
 6	 6	 Right	 Right
 7	 7	 Down	 Down
 8	 8	 Sleep	 Sleep
 9	 9	 FM Mode	 Smart
 0 / 10	 0	 Enter / Memory	 Media
 Display	 Info	 Auto Cal	 Options
 2 CH	 Red	 << / Tuning -	 <<
 AFD	 Green	 >> / Tuning +	 >>
 Movie	 Yellow	 D.Tuning	 Text



























































































Original	Replacement
	 Left
	 Play
	 Pause
	 Stop
	 <</Tuning-
	 >>/Tuning+
	 >>I/Preset+
	 I<</Preset-
	 ←/Replay
	 →/Advance
	 Media
	 +  Shift + Media
	 +  Shift + Dual
	 +  Shift + Pre Ch
	 +  Shift + 1
	 +  Shift + 2
	 +  Shift + 3


Original	Replacement
	 +  Shift + 4
	 +  Shift + 5
	 +  Shift + 6
	 +  Shift + 7
	 +  Shift + 8
	 +  Shift + 9
	 +  Shift + 0
	 3D
	 +  Shift + Ok
	 +  Shift + Up
	 +  Shift + Down
	 +  Shift + Right
	 +  Shift + Left
	 +  Shift + Ch -
	 +  Shift + Ch +
	 Text
	+  Shift + AV







Original	Replacement
 Power	 Power
 Play	 Play
 Stop	 Stop
 Auto Cal	 Smart
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0
 >10* CLEAR	 Guide
 OK	 Ok

Original	Replacement
 Enter/Memory	 Pre Ch
 Menu	 Menu
 Display	 Shift + Info
 Muting	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 FM Mode	 AV
 2CH	 Red
 A.F.D.	 Green
 Movie	 Yellow
 Music	 Blue
 Pause	 Pause
 >>/Tuning+	 >>











Original	Replacement
 Power	 Power
 Power AV	 +  Shift + Power
 Auto Cal	 Smart
 Sleep	 Sleep
 A.F.D.	 Green
 Movie	 Yellow
 Music	 Blue
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0/10	 0

Original	Replacement
 -/-->10	 +  Shift + Guide
 Enter/Memory	 Pre Ch
 FM Mode	 AV
 Display	 +  Shift + Info
 Muting	 Mute
 Vol+	 Vol +
 Vol-	 Vol -
 Menu	 Menu
 OK	 Ok
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 <</Tuning-	 <<





Original	Replacement
 >>/Tuning+	 >>
 >>I/Preset+	 >>I
 I<</Preset-	 I<<
 <-/Replay	 Ch -
 ->/Advance	 Ch +
 Video 2	 Media
 SA-CD/CD	 Shift + Media
 Power AV	 Info
 2CH	 Red
 D.Tuning/D.Skip SA-CD/CD	 Dual
 Enter/Memory SA-CD/CD	 Shift + Pre Ch
 1 SA-CD/CD	 Shift + 1
 2 SA-CD/CD	 Shift + 2
 3 SA-CD/CD	 Shift + 3
 4 SA-CD/CD	 Shift + 4
 5 SA-CD/CD	 Shift + 5
 6 SA-CD/CD	 Shift + 6

Original	Replacement
 7 SA-CD/CD	 Shift + 7
 8 SA-CD/CD	 Shift + 8
 9 SA-CD/CD	 Shift + 9
 0/10 SA-CD/CD	 Shift + 0
 -/->10 SA-CD/CD	 Guide
 Display SA-CD/CD	 3D
 Stop SA-CD/CD	 Shift + Stop
 Pause	 Shift + Pause
 Play SA-CD/CD	 Shift + Ok
 <</Tuning-	 Shift + Left
 >>/Tuning+	 Shift + Right
 I<</Preset-SA-CD/CD	 Shift + Ch -
 >>I/Preset+ SA-CD/CD	 Shift + Ch +

