







































































	Original	Replacement		Original	Replacement
	 Power	 Power		 Search >>I/Up	 >>I
	 1	 1		 I<<	 I<<
	 2	 2		 Tuner/Band	 TV/R
	 3	 3		 Auto Preset	 Smart
	 4	 4		 Tape >	 Right
	 5	 5		 < Tape	 Left
	 6	 6		 Stop Tape	 Ok
	 7	 7		 Rec/Pause Tape	 Rec
	 8	 8		 >> Tape	 >>
	 9	 9		 << Tape	 <<
	 10	 0		 Active Hyper-Bass	 Media
	 +10	 Guide		 Sound	 Dual
	 Sleep	 Sleep		 Volume+	 Vol +
	 Open/Close CD	 Eject		 Volume-	 Vol -
	 Play CD	 Play		 Treble+	 Ch +
	 Pause CD	 Pause		 Treble-	 Ch -
	 Stop/Clear CD	 Stop		 Bass+	 Up





Original	Replacement	Original	Replacement
	Bass-		Down
	Clock		AV
	Intro		Info
	Random		Options
	Repeat		Text
	Program		Shift + Sleep
	Edit		Exit
	Side A/B		3D
	Mode		Format
	Synchro Rec		Pre Ch

