







































































Original		Replacement		Original		Replacement	
	Power		Power		Vol-		Vol-
	Mute		Mute / Dimmer		HDMI		Shift + 0
	1		1		P-		CH- / Page-
	2		2		Media		Shift + Display / Media
	3		3		P.Mode		Picture / Format
	4		4		Home		Shift + Menu /
	5		5		S.Mode		Sound / Title
	6		6		Menu		Menu / Home
	7		7		Up		Up
	8		8		Source		AV / Input / RDS
	9		9		Left		Left
	Lang		Audio / Lang I/II		Enter		OK
	0		0		Right		Right
	Recall		Back / Return		Display		Display / Media
	Vol+		Vol+		Down		Down
	*/Setting		Setup / OPT /		Exit		Exit / Cancel / Clear
	P+		CH+ / Page+		Red		Red / Netflix / Search





	Original	Replacement	Original	Replacement
	Green	Green / APP / Repeat		
	Sub.T	Subtitle / EQ		
	Yellow	Yellow / YouTube / Repeat		
	Blue/Mouse	Blue / Prime Video / Random		
	Play	Play / Slow		
	Pause	Pause / Step / Freeze		
	Stop	Stop / Hold		
	<<	<< / Tune-		
	>>	>> / Tune+		
	I<<	I<< / Preset-		
	>>I	>>I / Preset+		
	Rec	Rec / Rec Mode		

