














































Original	Replacement	Original	Replacement
 Power Receiver	 Power	 Tuning -	 Ch -
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 Enter	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 Return / Repeat	 Back
 6	 6	 Info	 Info
 7	 7	 Phono	 Shift + 1
 8	 8	 Tape	 Shift + 2
 9	 9	 CD	 Shift + 3
 0	 0	 Line 1	 Shift + 4
 +10	 Guide	 Line 2	 Shift + 5
 Option	 Options	 Line 3	 Shift + 6
 Volume +	 Vol +	 Dock	 Shift + 7
 Volume -	 Vol -	 Tuner	 Shift + 8
 Tuning +	 Ch +	 TP	 Shift + 9







































Original		Replacement		Original	Replacement
	Speakers A		Red		
	Speakers B		Green		
	Enter2		Shift + Ok		
	Menu/▲		Menu		
	Display/▼		Shift + Info		
	Top Menu/Shuffle		Shift + Menu		
	Sleep		Sleep		
	FM		Smart		
	AM		Media		
	Preset+		Blue		
	Preset-		Yellow		
	Power Source		Text		
	Power Source Line 2/Line 3		AV		
	Dimmer		3D		





Original	Replacement
 Power Source	 Power
 Display	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide
 Enter	 Ok
 Play	 Play
 Pause	 Pause
 Stop	 Stop

Original	Replacement
 Disc Skip	 Blue
 >>	 >>
 <<	 <<
 >>	 >>
 <<	 <<
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute

