



Original	Replacement
Power	Power
Standby	+  Shift + Power
Sleep	Sleep / Timer
CD	+  3 Shift + 3
MD/CD-R	+  5 Shift + 5
DVD	+  2 Shift + 2
D-TV/CBL	+  1 Shift + 1
TUNER	+  6 Shift + 6
Multi CH In	+  0 Shift + 0
V-AUX	+  7 Shift + 7
DVR	+  4 Shift + 4
Volume +	Vol+
Volume -	Vol-
Mute	Mute / Dimmer
Stereo	1
Music	2
Entertain	3

Original	Replacement
Movie	4
Standard	5
Select	6
Extd Sur.	7
Direct ST	8
Speakers	9
Enhancer	Guide / EPG / -/--
Night	0
Straight	Fav / Marker / PC
Level	Sound / Title
Up / Preset/CH +	Up
Set Menu	Menu / Home
Left/-	Left
Enter	OK
Right/+	Right
Return	Back / Return
Down / Preset/CH	Down







Original	Replacement
Power	Power
Standby	+  Shift + Power
Sleep	Sleep / Timer
CD	+  3 Shift + 3
MD/CD-R	+  5 Shift + 5
DVD	+  2 Shift + 2
DTV/CBL	+  1 Shift + 1
Tuner	+  6 Shift + 6
Multi CH In	+  0 Shift + 0
V-AUX / Dock	+  7 Shift + 7
DVR	+  4 Shift + 4
Volume +	Vol+
Volume -	Vol-
Mute	Mute / Dimmer
1	1
2	2
3	3

Original	Replacement
4	4
5	5
6	6
7	7
8	8
9	9
0	0
ENT	Fav / Marker / PC
Band	Sound / Title
Preset+	Up
Preset+	>>  / Preset+
Srch Mode	Menu / Home
Left / A/B/C/D/E-	Left
Enter	OK
Right /	Right
Return	Back / Return
Preset-	Down



