







































































Original	Replacement	Original	Replacement
 POWER	 Power	 VOL+	 Vol +
 Open / Close	 Eject	 VOL-	 Vol -
 MUTE	 Mute	 SETUP	 Options
 DVD / TV Sys	 Smart	 PAUSE / Step	 Pause
 VIDEO	 Media	 Menu/Return	 Menu
 TUNER	 Shift + Media	 Menu / Return	 Back
 I<<	 I<<	 GOTO / Auto	 Guide
 <<	 <<	 PROGRESSIVE	 AV
 >>	 >>	 1	 1
 >>	 >>	 2	 2
 Up	 Up	 3	 3
 Down	 Down	 4	 4
 Right	 Right	 5	 5
 Left	 Left	 6	 6
 Enter	 Ok	 7	 7
 Play	 Play	 8	 8
 STOP	 Stop	 9	 9



