







































































Original	Replacement	Original	Replacement
 On	 Power	 OK	 Ok
 Standby	 Smart	 Up	 Up
 Play	 Play	 Down	 Down
 >>	 >>	 Right	 Right
 <<	 <<	 Left	 Left
 Pause	 Pause	 A/V Mute	 AV
 Stop	 Stop	 Aspect	 Format
 >>	 >>	 Pattern	 D. Menu
  <<	  <<	 Split	 Text
 Mute	 Mute	 RGBCMY	 Subt
 Vol+	 Vol +	 Auto Iris	 Dual
 Vol-	 Vol -	 2D/3D	 TV/R
 HDMI Link	 Media	 Color Mode	 Shift + Format
 Link Menu	 Info	 Memory	 Red
 Menu	 Menu	 USB	 1
 Esc	 Exit	 HDMI1	 2
 Default	 Back	 HDMI2	 3





Original	Replacement	Original	Replacement
Wireless HD	4		
Component	5		
Video	6		
PC	7		
User	B		

