







































































Original		Replacement		Original		Replacement	
	View DVD		Smart		Timer		Shift + AV
	View VCR		Media		F.ADV / Step		Pre Ch
	TV / VCR		TV/R		I<<		I<<
	Input SEL.		AV		Rec		Rec
	Standby / On		Power		Speed		Sleep
	Open / Close		Eject		>>I		>>I
	Info		Info		<<		<<
	1		1		Stop		Stop
	2		2		Play		Play
	3		3		Pause		Pause
	4		4		>>		>>
	5		5		TRK +		Vol +
	6		6		TRK -		Vol -
	7		7		Audio		Dual
	8		8		Prog +		Ch +
	9		9		Prog -		Ch -
	0		0		Menu		Menu





Original		Replacement		Original	Replacement
	Return		Back		
	Up		Up		
	Right		Right		
	Down		Down		
	Left		Left		
	OK		Ok		
	Disc Menu		D. Menu		
	Clear		Exit		
	Zoom		Shift + Eject		
	EZ View		Options		
	Subtitle		Subt		
	Angle / IPC		Format		
	Mode / Repeat		Text		
	Mark / Search		Shift + TV/R		

