
























































Original	Replacement	Original	Replacement
 Power	 Power	 TV/AV	 AV / Input / RDS
 Open/Close	 Eject / Surround	 P+	 CH+ / Page+
 Scan	 Display / Media	 TV/DVD	 Smart / List
 Swap	 Back / Return	 V-	 Vol-
 Call	 Shift + OK	 Menu	 Menu / Home
 Mute	 Mute / Dimmer	 V+	 Vol+
 1	 1	 Exit	 Exit / Cancel / Clear
 2	 2	 P-	 CH- / Page-
 3	 3	 P.STD	 Picture / Format
 4	 4	 Red/Picture	 Shift + Picture / Format
 5	 5	 Red/Picture	 Red / Netflix / Search
 6	 6	 Green/Sound	 Sound / Title
 7	 7	 Green/Sound	 Green / APP / Repeat
 8	 8	 Yellow/Time	 Yellow / YouTube / Repeat
 9	 9	 Blue/Function	 Blue / Prime Video / Random
 0	 0	 <<	 << / Tune-
 -/--	 Guide / EPG / -/--	 >>	 >> / Tune+













Original	Replacement
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Tune	 Shift + TV/Radio / Program
 Up	 Up
 Down	 Down
 Program	 TV/Radio /
 Zoom	 Zoom / Size
 D.Call	 Info / Angle
 [◆]	 Shift + Zoom /
 [-]	 D.Menu / Top
 [/ =]	 Shift + Text /
 [=]	 Text / Goto
 [X]	 Shift + Exit / Cancel / Clear
 [?]	 Setup / OPT /
 [+]	 Subtitle / EQ
 Timer	 Sleep / Timer
 >	 Right

Original	Replacement





Original	Replacement
 Power	 Power
 Open / Close	 Eject / Surround
 Scan	 Shift + Setup / OPT / Tools
 Swap	 Back / Return
 Call	 Smart / List
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide / EPG / -/--

Original	Replacement
 TV/AV	 AV / Input / RDS
 I-II	 Shift + Audio / Lang I/II
 P+	 CH+ / Page+
 TV/DVD	 Shift + 2
 TV/DVD	 Shift + 1
 V-	 Vol-
 MENU	 Menu / Home
 V+	 Vol+
 Exit	 Exit / Cancel / Clear
 P-	 CH- / Page-
 P.Std	 Picture / Format
 Red / Picture	 Red / Netflix / Search
 Red / Picture	 Shift + Picture / Format
 Green / Sound	 Green / APP / Repeat
 Green / Sound	 Shift + Sound / Title
 Yellow / Time	 Yellow / YouTube / Repeat
 Yellow / Time	 Sleep / Timer





Original	Replacement
Blue / Function	Blue / Prime Video / Random
Rev	<< / Tune-
Fwd	>> / Tune+
I<<	I<< / Preset-
>>I	>>I / Preset+
Stop	Stop / Hold
Setup	Setup / OPT /
Pause / Step	Pause / Step / Freeze
White / Tune	Display / Media
D.Menu	D.Menu / Top
Up	Up
Repeat	Shift + Green / APP /
A-B	Shift + Yellow / YouTube /
Left	Left
Play / Enter	Play / Slow
Play / Enter	OK
Right	Right

Original	Replacement
Slow	Shift + Play /
Angle	Info / Angle
Down	Down
Title / PBC	Sound / Title
Search	Shift + Red / Netflix /
Audio	Audio / Lang I/II
Program	TV/Radio /
Zoom	Zoom / Size
D.Call	Shift + Smart / List
10+	Shift + Guide / EPG / -/-
Caption	Subtitle / EQ
Hold	Shift + Stop /
[-]	Shift + TV/Radio / Program
Mix	Shift + Text /
Text	Text / Goto
[X]	Shift + Exit / Cancel / Clear
Reveal	Shift + Sleep / Timer





Original	Replacement	Original	Replacement
	Size +		
	Subcode +		
	> +		

