






































Original	Replacement	Original	Replacement
	Power		Power
	Stop		Stop
	Pause		Pause
	Rec		Rec
	Play		Play
	<<		<<
	>>		>>
	Tv Guide		Guide
	Setup		Menu
	[<>]/Format		Format
	Sources		AV
	Home		Smart
	Tv/Exit		Exit
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	OK		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Info		Info
	Back		Back
	Options		Options
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	PR+		Ch +
	PR-		Ch -
	1		1
	2		2
	3		3
	4		4





Original		Replacement		Original		Replacement	
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Text		Text				
	Subtitle		Subt				
	List		List				

