





































Original	Rechange
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PR+	 Ch +
 PR-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Input Select	 AV
 Display	 Info

Original	Rechange
 Time/Text	 Text
 Timer	 Shift + AV
 Tv/Video	 TV/R
 [...]	 Subt
 O)))	 Dual
 Clear	 Guide
 System Menu	 Menu
 Title List	 List
 Timer List	 Format
 Menu	 D. Menu
 Top Menu	 Shift + Menu
 Eject	 Eject
 Return	 Back
 Tools	 Options
 Enter	 Ok
 Up	 Up
 Down	 Down





Original	Recharge	Original	Recharge
	Right		Right
	Left		Left
	Play		Play
	Stop		Stop
	Pause		Pause
	>>/I>		>>
	<</<I		<<
	>>I		>>I
	I<<		I<<
	→		SHIFT +  Shift + Right
	←		SHIFT +  Shift + Left
	Visual Search		Blue
	Set		Pre Ch
	Sur		Sleep
	Rec		Rec
	Rec Pause		SHIFT +  Shift + Pause
	Rec Stop		SHIFT +  Shift + Stop
	Rec Mode		Shift + Rec
	Synchro Rec		3D
	Chapter Mark		Red
	Mark Erase		Shift + Eject
	Camera		Exit
	Progressive		Green
	[+]		Yellow
	Power Tv		Shift + Power
	HDD		Smart
	DVD		Media
	1 Tv		Shift + 1
	2 Tv		Shift + 2
	3 Tv		Shift + 3
	4 Tv		Shift + 4
	5 Tv		Shift + 5
	6 Tv		Shift + 6
	7 Tv		Shift + 7





Original	Recharge
 8 Tv	 Shift + 8
 9 Tv	 Shift + 9
 0 Tv	 Shift + 0
 -/--/Clear Tv	 Shift + Guide
 Prog + Tv	 Shift + Ch +
 Prog - Tv	 Shift + Ch -
 Tv/Video Tv	 Shift + TV/R

Original	Recharge

