







































































Original	Recharge
 Power	 Power
 Source	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV	 TV/R
 Recall	 Pre Ch
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute

Original	Recharge
 Home/@	 Smart
 +P	 Ch +
 -P	 Ch -
 Menu	 Menu
 Q.Menu	 D. Menu
 Back	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 WWW	 Media
 Music/Photo/Video	 Options
 Guide	 Guide
 Help	 Info
 */O	 Format





Original	Recharge
[=]	Text
Red	Red
Green	Green
Yellow	Yellow
Blue	Blue
Lang.	Dual
Sleep	Sleep
[-O-]	Subt
<<	<<
Pause	Pause
>>	>>
Rec	Rec
Play	Play
Stop	Stop

Original	Recharge

