







































































Original		Recharge		Original		Recharge	
	Standby		Power		Down		Down
	PVR Rec		Rec		Right		Right
	PVR List		List		Left		Left
	Mute		Mute		OK		Ok
	EPG		Guide		Vol+		Vol +
	Audio		Dual		Vol-		Vol -
	Info		Info		1		1
	DTV/VCR		Smart		2		2
	TTX		Text		3		3
	Subtitle		Subt		4		4
	Menu		Menu		5		5
	Exit		Exit		6		6
	Tv/Radio		TV/R		7		7
	Favourite		Pre Ch		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Recall		Back









































































	Original	Rechange	Original	Rechange
	Goto	3D		
	<<	<<		
	>>	>>		
	I<<	I<<		
	>>I	>>I		
	Play	Play		
	Pause	Pause		
	Stop	Stop		
	RPT	Media		
	Red	A Red		
	Green	B Green		
	Yellow	C Yellow		
	Blue	D Blue		





Original		Rechange		Original		Rechange	
	Standby		Power		Down		Down
	PVR Rec		Rec		Right		Right
	PVR List		List		Left		Left
	Mute		Mute		OK		Ok
	EPG		Guide		Vol+		Vol +
	Audio		Dual		Vol-		Vol -
	Info		Info		1		1
	DTV/VCR		Smart		2		2
	TTX		Text		3		3
	Subtitle		Subt		4		4
	Menu		Menu		5		5
	Exit		Exit		6		6
	Tv/Radio		TV/R		7		7
	Favourite		Pre Ch		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Recall		Back





	Original	Rechange	Original	Rechange
	Goto	 3D		
	<<			
	>>			
	I<<			
	>>I			
	Play			
	Pause			
	Stop			
	RPT			
	Red			
	Green			
	Yellow			
	Blue			

