






















































































Original	Recharge	Original	Recharge
 Power	 Power	 Blue/Picture	 Blue
 Mute	 Mute	 O/I/I	 Dual
 1	 1	 Menu	 Menu
 2	 2	 Up	 Up
 3	 3	 Down	 Down
 4	 4	 Right	 Right
 5	 5	 Left	 Left
 6	 6	 OK	 Ok
 7	 7	 [≡]	 Text
 8	 8	 Back	 Back
 9	 9	 P+	 Ch +
 0	 0	 P-	 Ch -
 i	 Info	 Vol+	 Vol +
 AV	 AV	 Vol-	 Vol -
 Red/Zoom	 Red	 ^/[+]	 Format
 Green/(↔)	 Green	 Play/[?]	 Play
 Yellow/Timer	 Yellow	 >>/[♦]	 >>









































































	Original	Rechange	Original	Rechange
	√/Timer	 OPT Options		
	Stop/[X]	 Stop		
	Pause/[≡i]	 Pause		
	[■]	 AD SUBT Subt		
	[←■]	 SEARCH TV/R TV/R		
	[↕■]	 ECO 3D 3D		
	♪	 SHIFT +  SOUND DUAL Shift + Dual		











































































Original		Rechange		Original		Rechange	
	Power		Power		P-		Ch -
	Mute		Mute		Vol+		Vol +
	1		1		Vol-		Vol -
	2		2		Red/Zoom		Red
	3		3		Green/(↔)		Green
	4		4		Yellow/Timer		Yellow
	5		5		Blue/Picture		Blue
	6		6		<<		<<
	7		7		>>/[◆]		>>
	8		8		^[+]		Format
	9		9		~/Timer		Options
	0		0		Rec/Top Menu		Rec
	AV		AV		Play/[?]		Play
	i		Info		Stop/[X]		Stop
	O/I/II		Dual		Pause/[≡i]		Pause
	[≡]		Text		[■]		Subt
	P+		Ch +		[←■]		TV/R


























Original	Rechange	Original	Rechange
 Power	 Power	 Green/(↔)	 Green
 Mute	 Mute	 Yellow/Timer	 Yellow
 1	 1	 Blue/Picture	 Blue
 2	 2	 OK	 Ok
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 P+	 Ch +
 8	 8	 P-	 Ch -
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 i	 DISPLAY INFO	 <<	 <<
 AV	 TIMER AV	 Play/[?]	 Play
 O)/I/II	 SOUND DUAL	 >>/[♦]	 >>
 Menu	 TOP MENU MENU	 Stop/[X]	 Stop
 ZOOM	 A	 Pause/[≡i]	 Pause





Original		Rechange		Original		Rechange	
	^/[+]		Format				
	~/Timer		Options				
	[ ■ ]		Subt				
	[ ←■ ]		TV/R				
	[ ↕■ ]		3D				
	♪		Shift +		Dual		
	Back		Back				
	[ ≡ ]		Text				

