





































Original	Recharge
 Power	 Power
 Mute	 Mute
 FAV	 Pre Ch
 Subtitle	 Subt
 Info	 Info
 TTX	 Text
 Recall	 Back
 USB	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Original	Recharge
 0	 0
 Menu	 Menu
 Exit	 Exit
 Up / CH +	 Up
 Up / CH +	 Ch +
 Down / CH -	 Down
 Down / CH -	 Ch -
 Right / Vol +	 Right
 Right / Vol +	 Vol +
 Left / Vol -	 Left
 Left / Vol -	 Vol -
 OK	 Ok
 Pg Dn	 Shift + Ch -
 Pg Up	 Shift + Ch +
 >>	 >>
 <<	 <<
 >>	 >>



