



| Original | Rechange | Original | Rechange |
|----------|----------|----------|-----------------------|
| | Mute | | Mute / Dimmer |
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | (T) | | Display / Media |
| | 0 | | 0 |
| | List | | Smart / List |
| | Vol+ | | Vol+ |
| | [i] | | Info / Angle |
| | P+ | | CH+ / Page+ |
| | Vol- | | Vol- |
| | * | | Setup / OPT / |
| | P- | | CH- / Page- |
| | Home | | Menu / Home |
| | Up | | Up |
| | ≡ | | D.Menu / Top |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | ← | | Back / Return |
| | Down | | Down |
| | Source | | AV / Input / RDS |
| | Exit | | Exit / Cancel / Clear |
| | Guide | | Guide / EPG / -/- |
| | Text | | Text / Goto |
| | O)/Lang | | Audio / Lang I/II |
| | Subt. | | Subtitle / EQ |



