






































Original	Rechange
 Power	 Power
 Sleep	 Sleep
 CBL/SAT	 1
 DVD	 2
 Blu-ray	 3
 Game	 4
 AUX	 5
 Media Player	 6
 Phono	 7
 TV Audio	 8
 Tuner	 9
 USB	 Guide
 Bluetooth	 0
 Internet Radio	 Pre Ch
 Eco	 Media
 Eco	 3D
 CH/Page Up	 Ch +

Original	Rechange
 CH/Page Down	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Info	 Info
 Option	 Options
 Back	 Back
 Setup	 Menu
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 I<</Tune-	 I<<
 Play	 Play
 Pause	 Pause
 >>I/Tune+	 >>I









Original		Rechange		Original		Rechange	
	Power		Power		Vol+		Vol +
	Sleep		Sleep		Vol-		Vol -
	CBL/SAT		1		Mute		Mute
	DVD		2		Back		Back
	Blu-ray		3		Up		Up
	Game		4		Down		Down
	AUX		5		Right		Right
	Media Player		6		Left		Left
	Phono		7		Enter		Ok
	TV Audio		8		I<</Tune-		I<<
	Tuner		9		Play		Play
	USB		Guide		Pause		Pause
	Bluetooth		0		>>I/Tune+		>>I
	Internet Radio		Pre Ch		Quick Select 1		D. Menu
	ECO		Media		Quick Select 2		Text
	CH/Page Up		Ch +		Quick Select 3		Eject
	CH/Page Down		Ch -		Quick Select 4		AV

