



Original	Rechange
On / Standby	Power
Input Selector V1	1
Input Selector V2	2
Input Selector V3	3
Input Selector Multi CH	5
Input Selector	6
Input Selector	7
Input Selector Tuner	8
Input Selector CD	9
Dimmer	0
Sleep	Sleep / Timer
Guide/Top	Menu / Home
Muting	Mute / Dimmer
Return	Back / Return
Setup	Eject / Surround
Enter	OK
Up	Up

Original	Rechange
Down	Down
Right	Right
Left	Left
Play	Play / Slow
Rev. Play	Pause / Step / Freeze
Stop	Stop / Hold
<<	>> / Tune+
>>	I<< / Preset-
I<<	<< / Tune-
>>I	>>I / Preset+
Listening Mode Stereo	Red / Netflix / Search
Listening Mode Surround	Green / APP / Repeat
Listening Mode <	Yellow / YouTube / Repeat
Listening Mode >	Blue / Prime Video / Random
Test Tone/Audio	Audio / Lang I/II
CH Sel/Subtitle	Subtitle / EQ
Level-/Random	TV/Radio /





Original	Rechange
Level+/Repeat	Zoom / Size
Display	Info / Angle
L.Night	Smart / List
Cine FLTR	Display / Media
Input Tv	Shift + AV / Input / RDS
CH/Disc/Album	CH+ / Page+
CH/Disc/Album-	CH- / Page-
Vol+	Vol+
Vol-	Vol-
Power Tv/Standby	Shift + Power
Vol+ Tv	Shift + Vol+
Vol- Tv	Shift + Vol-
1 Tv	Shift + 1
2 Tv	Shift + 2
3 Tv	Shift + 3
4 Tv	Shift + 4
5 Tv	Shift + 5

Original	Rechange
6 Tv	Shift + 6
7 Tv	Shift + 7
8 Tv	Shift + 8
9 Tv	Shift + 9
0 Tv	Shift + 0
+10 Tv	Shift + Guide / EPG / -/-
Muting/Previous Menu Tv	Shift + Mute / Dimmer
Enter Tv	Shift + OK
Right Tv	Shift + Right
Left Tv	Shift + Left
Setup Tv	D.Menu / Top
Up Tv	Shift + Up
Down Tv	Shift + Down





Original	Rechange
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
VCR	+  4 Shift + 4
+10/10/-/-	Guide / EPG / -/-
0/11	0
CLR	Exit / Cancel / Clear
Top Menu	D.Menu / Top
Up	Up
Previous Menu/Muting	Menu / Home





























Original	Rechange
Previous Menu/Muting	Mute / Dimmer
Left/Playlist/Cat-	Left
Enter	OK
Right/Playlist/Cat	Right
Return	Back / Return
Down	Down
Setup	Setup / OPT /
Pause	Pause / Step / Freeze
Play	Play / Slow
Stop	Stop / Hold
<<	<< / Tune-
>>	>> / Tune+
I<<	I<< / Preset-
>>I	>>I / Preset+
Stereo	Sound / Title
Surround	Eject / Surround
< Listening Mode	+  Shift + I<< / Preset-







Original	Rechange
 On / Standby	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 +10/10/-/-	 Guide / EPG / -/-
 0/11	 0
 12	 Fav / Marker / PC
 Disc+	 CH+ / Page+
 Vol+	 Vol+
 Disc-	 CH- / Page-
 Vol-	 Vol-

Original	Rechange
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 Stop	 Stop / Hold
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Stereo	 Audio / Lang I/II
 Surround	 Eject / Surround
 < Listening Mode	 Shift + I<< / Preset-
 Listening Mode >	 Shift + >>I / Preset+
 Random	 Blue / Prime Video / Random
 Repeat	 Green / APP / Repeat
 Display	 Display / Media



