






















Original	Recharge
 Power	 Power
 Mute	 Mute / Dimmer
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 <</Zoom+	 << / Tune-
 >>/Zoom-	 >> / Tune+
 Lan/Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 Zoom	 Zoom / Size
 Tv/Radio	 TV/Radio /
 Text	 Text / Goto
 Menu	 Menu / Home
 Up	 Up
 Info	 Info / Angle
 Left	 Left
 OK	 OK
 Right	 Right

Original	Recharge
 Exit	 Exit / Cancel / Clear
 Down	 Down
 Recall	 Back / Return
 V+	 Vol+
 Auto	 Smart / List
 Ch+	 CH+ / Page+
 V-	 Vol-
 Game	 Display / Media
 CH-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8



