







































































Original	Rechange	Original	Rechange
	Power		Power
	Mute		Mute / Dimmer
	TV/RAD		TV/Radio /
	www		Sleep / Timer
	PIP		Zoom / Size
	Grid		D.Menu / Top
	Swap		Back / Return
	Sub ch		Setup / OPT /
	P/Pg+		CH+ / Page+
	RCL		Display / Media
	Vol+		Vol+
	P/Pg-		CH- / Page-
	i		Info / Angle
	Vol-		Vol-
	FAV		Fav / Marker / PC
	Check		Smart / List
	Message		Eject / Surround
	EPG		Guide / EPG / -/-
	Up		Up
	Menu		Menu / Home
	Left		Left
	OK		OK
	right		Right
	Exit		Exit / Cancel / Clear
	Down		Down
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	1		1
	2		2
	3		3
	4		4
	5		5



