





































Original	Rechange
 Power	 Power
 Mute	 Mute
 Display	 Info
 Exit	 Exit
 TV / AV	 AV
 SYS	 Smart
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 -/--	 Guide

Original	Rechange
 Recall	 Pre Ch
 V +	 Vol +
 V -	 Vol -
 P +	 Ch +
 P -	 Ch -
 Up	 Up
 Left	 Left
 Menu	 Menu
 Menu	 Ok
 Right	 Right
 Down	 Down
 SMode	 Format
 PMode	 Shift + Dual
 Sleep	 Sleep
 Nicam	 Dual
 Hold	 Stop
 Index	 Media





Original		Recharge	
PGUP	PGUP		Shift + Ch +
SIZE	Size		Eject
PGDN	PGDN		Shift + Ch -
TEXT	Text		Text
REVEAL	Reveal		Options
SUBPAGE	Subpage		Subt
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue

Original		Recharge	

