







































































Original		Rechange		Original		Rechange	
	Power		Power		Right		Right
	1		1		Left		Left
	2		2		OK		Ok
	3		3		PR+		Ch +
	4		4		PR-		Ch -
	5		5		Vol+		Vol +
	6		6		Vol-		Vol -
	7		7		Menu		Menu
	8		8		TV		TV/R
	9		9		Video		AV
	0		0		L/?		Guide
	Red/M		Red		L/?		Dual
	Green		Green		PC		Pre Ch
	Yellow		Yellow		Text		Text
	Blue		Blue		F[+]		3D
	Up		Up		Hold/Freeze		Format
	Down		Down		M/S		Options





	Original		Recharge	
	Mute		Mute	
	PIP		Media	
	Auto/Page		Smart	
	i		Info	
	Timer/Mix		Subt	
	F1	 + 	Shift + 1	
	F2	 + 	Shift + 2	
	F3	 + 	Shift + 3	
	F4	 + 	Shift + 4	

	Original		Recharge

