



























Original	Recharge	Original	Recharge
	Power		Power
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	White		Shift + Blue
	Guide		Guide
	[⊞]		Shift + Power
	[?]		Smart
	[↕]		3D
	Text		Text
	□→		AV
	□→		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]		Info





Original		Recharge		Original	Recharge
	P<P / -/--		Pre Ch		
	I-II		Shift + Dual		
	▶ ◀		Stop		
	[1 2]		Media		
	[◆]		TV/R		
	Smart Audio		Dual		
	Smart Picture		Format		
	[[◀▶]]		Shift + Format		
	Rec DNR		Rec		

