



































Original		Recharge		Original		Recharge	
	Power		Power		Vol+ Tv		Vol+
	Power Tv		Shift + Power		Rec		Rec / Rec Mode
	DVD		Shift + 2		0		0
	VCR		Shift + 4		AV Input		AV / Input / RDS
	Eject/Open-Close		Eject / Surround		Vol- Tv		Vol-
	AV Input Tv		Shift + AV / Input / RDS		<< Scan		<< / Tune-
	1		1		Scan >>		>> / Tune+
	2		2		I<< Skip		I<< / Preset-
	3		3		Skip >>I		>>I / Preset+
	PR+ Tv		Shift + CH+ /		Pause/Step		Pause / Step / Freeze
	4		4		Play		Play / Slow
	5		5		Stop		Stop / Hold
	6		6		Home		Menu / Home
	PR- Tv		Shift + CH- /		PR/TRK+		CH+ / Page+
	7		7		Up		Up
	8		8		Menu/List		D.Menu / Top
	9		9		Left		Left





Original		Rechange	
	Enter		OK
	Right		Right
	Return		Back / Return
	Down		Down
	PR/TRK-		CH- / Page-
	Display		Display / Media
	O))/Audio		Audio / Lang I/II
	Title		Sound / Title
	Marker		Fav / Marker / PC
	Clear		Exit / Cancel / Clear
	Red/FAV		Red / Netflix / Search
	Green/Repeat		Green / APP / Repeat
	Yellow/Subtitle		Yellow / YouTube / Repeat
	Blue/Text		Blue / Prime Video / Random
	EPG		Guide / EPG / -/--
	Dubbing		Picture / Format

Original		Rechange	

