







































































Original		Rechange		Original		Rechange	
	Power		Power		Vol-		Vol-
	Source		AV / Input / RDS		i/Info		Info / Angle
	1		1		PR-		CH- / Page-
	2		2		Menu		Menu / Home
	3		3		Up		Up
	4		4		Q.Menu		D.Menu / Top
	5		5		Left		Left
	6		6		OK		OK
	7		7		Right		Right
	8		8		Back		Back / Return
	9		9		Down		Down
	TV		TV/Radio /		Exit		Exit / Cancel / Clear
	0		0		World		Smart / List
	Recall		Fav / Marker / PC		Music Photo		Display / Media
	Vol+		Vol+		Guide		Guide / EPG / -/--
	Mute		Mute / Dimmer		*/o		Setup / OPT /
	PR+		CH+ / Page+		*/o..		Zoom / Size



