



Original	Recharge
Power	Power
Auto Off	Shift + Power
Sleep	Sleep / Timer
Muting	Mute / Dimmer
1	1
2	2
3	3
Disc	Display / Media
4	4
5	5
6	6
+10	Guide / EPG / -/--
7	7
8	8
9	9
0	0
Program	TV/Radio /

Original	Recharge
Cancel	Exit / Cancel / Clear
Repeat	Green / APP / Repeat
Random	Blue / Prime Video / Random
Tape	Shift + 5
CD	Shift + 3
Tuner	Shift + 6
AUX	Shift + 7
EQ	Subtitle / EQ
3D AI	Smart / List
<<	<< / Tune-
<<	<< / Preset-
>>	>> / Preset+
>>	>> / Tune+
V.Bass	Sound / Title
</v	Left
</v	Down
</v	CH- / Page-



Program

