






Original	Rechange	Original	Rechange
	Power		Power
	Mute		Mute / Dimmer
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	<<		<< / Tune-
	>>		>> / Tune+
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	S.Mode		Sound / Title
	Audio/Reveal		Audio / Lang I/II
	Zoom/Subpage		Subtitle / EQ
	P.Mode		Picture / Format
	Size		Zoom / Size
	Sleep		Sleep / Timer
	D.Menu		D.Menu / Top
	Text		Text / Goto
	Input		AV / Input / RDS
	LCD Menu		Menu / Home
	Up		Up
	Index		Info / Angle
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Recall		Back / Return
	Vol+		Vol+
	DVD Setup		Smart / List
	CH+		CH+ / Page+
	Vol-		Vol-
	Display		Display / Media
	CH-		CH- / Page-
	1		1
	2		2





Original	Rechange
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 -/--	 Guide / EPG / -/--
 0	 0
 Auto	 Fav / Marker / PC
 Red/Program	 Red / Netflix / Search
 Green/Intro	 Green / APP / Repeat
 Yellow/Repeat	 Yellow / YouTube / Repeat
 Blue/A-B	 Blue / Prime Video / Random
 Hold	 Shift + Stop /
 Title	 Shift + Sound / Title
 Nicam	 Shift + Audio / Lang I/II

Original	Rechange
 Aspect	 Shift + Picture / Format
 D.Subt.	 Shift + Zoom /
 Goto	 Shift + Text /
 Angle	 Shift + Info / Angle
 Slow/PgUp	 Shift + CH+ /
 D.Disp	 Shift + Display / Media
 Step/PgDn	 Shift + CH- /

