







































































Original		Rechange		Original		Rechange	
	Standby		Power		Down		Down
	Rec PVR		Rec		Right		Right
	List PVR		Smart		Left		Left
	Mute		Mute		OK		Ok
	EPG		Guide		Vol+		Vol +
	Audio		Dual		Vol-		Vol -
	Info		Info		1		1
	DTV/VCR		Media		2		2
	TTX		Text		3		3
	Subtitle		Subt		4		4
	Menu		Menu		5		5
	Exit		Exit		6		6
	Favourite		Pre Ch		7		7
	Tv/Radio		TV/R		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Recall		Back









































































	Original	Recharge	Original	Recharge
	Goto	 AV		
	<<			
	>>			
	I<<			
	>>I			
	Play	 Play		
	Pause			
	Stop			
	Repeat	 +  Shift + Text		
	Red	 Red		
	Green	 Green		
	Yellow	 Yellow		
	Blue	 Blue		





Original		Recharge		Original		Recharge	
	Standby		Power		Down		Down
	Rec PVR		Rec		Right		Right
	List PVR		List		Left		Left
	Mute		Mute		OK		Ok
	EPG		Guide		Vol+		Vol +
	Audio		Dual		Vol-		Vol -
	Info		Info		1		1
	DTV/VCR		Media		2		2
	TTX		Text		3		3
	Subtitle		Subt		4		4
	Menu		Menu		5		5
	Exit		Exit		6		6
	Favourite		Pre Ch		7		7
	Tv/Radio		TV/R		8		8
	CH+		Ch +		9		9
	CH-		Ch -		0		0
	Up		Up		Recall		Back





	Original	Recharge	Original	Recharge
	Goto	OPT		Options
	<<			<<
	>>			>>
	<<			<<
	>>			>>
	Play			Play
	Pause			Pause
	Stop			Stop
	Repeat	+ REPEAT TEXT		Shift + Text
	Red			Red
	Green			Green
	Yellow			Yellow
	Blue			Blue

