







































































Original	Recharge
 Power	 Power
 Source	 AV / Input / RDS
 Size	 Zoom / Size
 [ > < ]	 Picture / Format
 A/B	 Shift + Yellow / YouTube /
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 [   ]	 Guide / EPG / -/--
 Up	 Up
 [i+]	 Info / Angle
 Left	 Left
 OK	 OK
 Right	 Right
 Return	 Back / Return
 Down	 Down

Original	Recharge
 Tools	 Setup / OPT /
 Menu	 Menu / Home
 Analog	 Display / Media
 Digital	 Smart / List
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Text	 Text / Goto
 0	 0
 Recall	 Fav / Marker / PC
 Mute	 Mute / Dimmer



