Original	Replacement	Original	Replacement
Power	Power	0	0
Up	Up	Recall	Back
Down	Down	-/--	Guide
Right	Right	[◁ ▷]	Format
Left	Left	P/CH+	Ch +
OK	Ok	P/CH-	Ch -
M	Menu	Vol +	Vol +
[i]	Info	Vol -	Vol -
1	1	Mute	Mute
2	2	I-II	Dual
3	3	TV	TV/R
4	4	EXT	AV
5	5	Red	Red
6	6	Green	Green
7	7	Yellow	Yellow
8	8	Blue	Blue
9	9	[=]	Text

Original		Replacement		Original	Replacement
	[=o]	AD SUBT	Subt		
	[=+]	ECO 3D	3D		
	[=x]	SETTINGS OPT	Options		
	[/=]	HOME SMART	Smart		
	[=♦]	APP MEDIA	Media		
	[=?]	FAV PRE-CH	Pre Ch		
	[=i]	DISC NAV LIST	List		