Original		Replacement		Original		Replacement	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer	PR	Down / PR -	CH PAGE −	CH- / Page-
POWER	Power	POWER	Power	OK	OK	OK	OK
PICTURE	Picture	FORMAT PICTURE	Picture / Format	P.MODE	Red / P.Mode	NETFLIX SEARCH	Red / Netflix / Search
SOUND	Sound	TITLE SOUND	Sound / Title	P.STILL	Green / P.Stil	APP REPEAT	Green / APP / Repeat
MULTI MEDIA	Multimedia	MEDIA DISPLAY	Display / Media	P.SWAP	Yellow / P.Swa	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Source	RDS AV INPUT	AV / Input / RDS	P.INPUT	Blue / P.Input	Prime Video RANDOM	Blue / Prime Video / Random
ASPECT	Aspect	SHIFT +	FORMAT PICTURE Shift + Picture / Format	DYNAMIC BASS	Dynamic Bass	LIST SMART	Smart / List
PR	Up / PR +	CH PAGE +	CH+ / Page+	3D-PANORAMA	3D - Panorama	PROGRAM TV/RADIO	TV/Radio /
PR	Up / PR +		Up	P.PR ▲	P.PR +	SHIFT + CH PAGE +	Shift + CH+ /
RECALL	Recall	RETURN BACK	Back / Return	D/CD/I/II	Audio I / II	LANG I/II AUDIO	Audio / Lang I/II
VOL	Left / Vol -		Left	STILL	Still	STEP-FREEZE	Pause / Step / Freeze
VOL	Left / Vol -	VOL −	Vol -	P.PR ▼	P.PR -	SHIFT + CH PAGE −	Shift + CH- /
MENU	Menu	HOME MENU	Menu / Home	1	1	TV 1	1
VOL	Right / Vol +	VOL +	Vol +	2	2	DVD 2	2
VOL	Right / Vol +		Right	3	3	CD-STB 3	3
PREV PR	Prev PR	PC FAV MARKER	Fav / Marker / PC	4	4	VIDEO 4	4
PR	Down / PR -		Down	5	5	TAPE 5	5

Original		Replacement		Original	
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
LOCK	Lock	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
0	0	HDMI - SAT 0	0		
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer		
[≡]	[≡]	GOTO TEXT	Text / Goto		
[≡?]	[≡?]	SURROUND ⏏	Eject / Surround		
[≡X]	[≡X]	EQ SUBTITLE	Subtitle / EQ		
Size	Size	SIZE ZOOM	Zoom / Size		
[≡o]	[≡o]	-/-- GUIDE EPG	Guide / EPG / -/--		
Hold	Hold	HOLD ■	Stop / Hold		
[/≡]	[/≡]	OPT-TOOLS SETUP	Setup / OPT /		
[≡i]	[≡i]	ANGLE INFO	Info / Angle		