Original	Replacement	Original	Replacement
Standby	Power	Menu	Menu
Mute	Mute	EPG	Guide
1	1	Exit	Exit
2	2	CH+	Ch +
3	3	CH-	Ch -
4	4	Up	Up
5	5	Down	Down
6	6	Right	Right
7	7	Left	Left
8	8	OK	Ok
9	9	Vol+	Vol +
0	0	Vol-	Vol -
FAV	Pre Ch	Text	Text
Audio	Dual	Red	Red
Recall	Back	Green	Green
Subtitle	Subt	Yellow	Yellow
Info	Info	Blue	Blue

Original		Replacement		Original	Replacement
REC LIST	Rec List	DISC NAV LIST	List		
TV/RADIO	Tv/Radio	SEARCH TV/R	TV/R		
STOP	Stop		Stop		
PAUSE	Pause		Pause		
REV	<<		<<		
FWD	>>		>>		
RECORD	Record	REC MODE	Rec		