Original		Replacement	
Power		Power	
Input Selector		AV	
FM/AM		SHIFT + 1	Shift + 1
TV		SHIFT + 2	Shift + 2
DVD Recorder		SHIFT + 3	Shift + 3
BD/DVD Player / Analog 8CH		SHIFT + 4	Shift + 4
Cable / Sat		SHIFT + 5	Shift + 5
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	

Original		Replacement	
>10		GUIDE	Guide
Direct Tuning		OK	Ok
CH+		CH +	Ch +
CH+			Up
CH-			Down
CH-		CH −	Ch -
Vol +		VOL +	Vol +
Vol -		VOL −	Vol -
Muting		MUTE	Mute
Drive Select		APP MEDIA	Media
Tune-			Left
<< PORT			<<
Tune+			Right
>> PORT			>>
Stop PORT			Stop
Pause PORT			Pause
Play PORT		PLAY MODE	Play

Original		Replacement		Original		Replacement	
	I << PORT		I <<				
	>>I PORT		>>I				
ONE TOUCH PLAY	One Touch Play	HOME SMART	Smart				
SURROUND OFF	Surround Off	SHIFT +	A Shift + Red				
PLIIx	PL IIx		A Red				
NEO:6	NEO:6		B Green				
MUSIC	SFC Music		C Yellow				
MOVIE	SFC Movie		D Blue				
AUTO TEST	Test / Auto	REPEAT TEXT	Text				
SOUND MENU	Sound Menu	SOUND DUAL	Dual				
DISPLAY	Display	DISPLAY INFO	Info				
OPTION PORT	Option Port /	SETTINGS OPT	Options				
VOL +	TV Vol +	SHIFT +	VOL + Shift + Vol +				
VOL -	TV Vol -	SHIFT +	VOL - Shift + Vol -				
TV/VIDEO	TV/Video	SEARCH TV/R	TV/R				

Original		Replacement	
Power	Power	Power	
Input Selector	Input Selector	TIMER AV	AV
FM/AM	FM/AM	SHIFT + 1	Shift + 1
AV SYSTEM	DVD Power	SHIFT +	Shift + Power
TV	TV	SHIFT + 2	Shift + 2
RECORDER DVD	DVD Recorder	SHIFT + 3	Shift + 3
PLAYER BD/DVD	BD/DVD Player / Analog 8CH	SHIFT + 4	Shift + 4
CABLE SAT	Cable / Sat	SHIFT + 5	Shift + 5
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
≥10	>10	-/-- GUIDE	Guide
CH	CH+	CH	Ch +
CH	CH-	CH	Ch -
VOL	Vol +	VOL	Vol +
VOL	Vol -	VOL	Vol -
MUTING	Muting	MUTE	Mute
DRIVE SELECT	Drive Select	APP MEDIA	Media
<<	<<	<<	<<
>>	>>	>>	>>
STOP	Stop	■	Stop
PAUSE	Pause	II	Pause
PLAY	Play	PLAY MODE ▶	Play
I<<	I<<	I<<	I<<
>>I	>>I	>>I	>>I
ONE TOUCH PLAY	One Touch Play	HOME SMART	Smart
TOP MENU / DIRECT NAVIGATOR	Top Menu / Direc Navigator	DISC NAV LIST	List

Original		Replacement	
FUNCTIONS	Functions DVD Recorder	SHIFT + TOP MENU / MENU	Shift + Menu
FUNCTIONS	Functions DVD Player	TOP MENU / MENU	Menu
▲	Up	▲	Up
◀	Left	◀	Left
OK	OK	OK	Ok
▶	Right	▶	Right
▼	Down	▼	Down
SUB MENU / S	Sub Menu	E-MANUAL / D.MENU	D. Menu
RETURN	Return	RETURN / BACK	Back
SURROUND / OFF	Surround Off	SHIFT + A	Shift + Red
PLIIx	PL IIx	A	Red
NEO:6	NEO: 6	B	Green
MUSIC	SFC Music	C	Yellow
MOVIE	SFC Movie	D	Blue
AUTO / TEST	Test / Auto	REPEAT / TEXT	Text
SOUND / MENU	Sound Menu	SOUND / DUAL	Dual
DISPLAY	Display	DISPLAY / INFO	Info

Original		Replacement	
OPTION PORT	Option Port /	SETTINGS / OPT	Options
+ VOL	TV Vol +	SHIFT + + CH	Shift + Ch +
VOL −	TV Vol -	SHIFT + CH −	Shift + Ch -
TV/VIDEO	TV/ Video	SEARCH / TV/R	TV/ R

Original		Replacement	
	Power		Power
INPUT SELECTOR	Input Selector	TIMER AV	AV
FM/AM	FM/AM	SHIFT + 1	Shift + 1
AV SYSTEM	TV Power	SHIFT +	Shift + Power
TV	TV	SHIFT + 2	Shift + 2
RECORDER DVD	DVD Recorder	SHIFT + 3	Shift + 3
PLAYER BD/DVD	BD/DVD Player / Analog 8CH	SHIFT + 4	Shift + 4
CABLE SAT	Cable / Sat	SHIFT + 5	Shift + 5
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
≥10	>10	-/-- GUIDE	Guide
CH	CH+	+ CH	Ch +
CH	CH-	CH −	Ch -
+ VOL	Vol +	+ VOL	Vol +
VOL −	Vol -	VOL −	Vol -
MUTING	Muting	MUTE	Mute
DRIVE SELECT	Drive Select	APP MEDIA	Media
ONE TOUCH PLAY	One Touch Play	HOME SMART	Smart
FUNCTIONS	Functions	TOP MENU MENU	Menu
	Up		Up
	Left		Left
OK	OK	OK	Ok
	Right		Right
	Down		Down
SUB MENU S	Sub Menu	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back

Original		Replacement		Original	Replacement
SURROUND OFF	Surround Off	SHIFT + A	Shift + Red		
PLIIx	PL IIx	A	Red		
NEO:6	NEO:6	B	Green		
MUSIC	SFC Music	C	Yellow		
MOVIE	SFC Movie	D	Blue		
AUTO TEST	Test / Auto	REPEAT TEXT	Text		
SOUND MENU	Sound Menu	SOUND DUAL	Dual		
DISPLAY	Display	DISPLAY INFO	Info		
OPTION PORT	Option Port /	SETTINGS OPT	Options		
VOL +	TV Vol +	SHIFT + CH +	Shift + Ch +		
VOL −	TV Vol -	SHIFT + CH −	Shift + Ch -		
TV/VIDEO	TV/Video	SEARCH TV/R	TV/R		

Original		Replacement	
	Power		Power
	Input Selector	TIMER AV	AV
	FM/AM	SHIFT + 1	Shift + 1
	Power	SHIFT +	Shift + Power
	TV	SHIFT + 2	Shift + 2
	DVD Recorder	SHIFT + 3	Shift + 3
	BD/DVD Player / Analog 8CH	SHIFT + 4	Shift + 4
	Cable / Sat	SHIFT + 5	Shift + 5
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
CH	CH+	CH	Ch +
CH	CH-	CH	Ch -
VOL	Vol +	VOL	Vol +
VOL	Vol -	VOL	Vol -
MUTING	Muting	MUTE	Mute
DRIVE SELECT	Drive Select	APP MEDIA	Media
ONE TOUCH PLAY	One Touch Play	HOME SMART	Smart
SURROUND OFF	Surround Off	SHIFT + A	Shift + Red
PLIIx	PL IIx	A	Red
NEO:6	NEO:6	B	Green
MUSIC	SFC Music	C	Yellow
MOVIE	SFC Movie	D	Blue
AUTO TEST	Test / Auto	REPEAT TEXT	Text
SOUND MENU	Sound Menu	SOUND DUAL	Dual
DISPLAY	Display	DISPLAY INFO	Info
OPTION PORT	Option Port / Setup	SETTINGS OPT	Options

Original	Replacement	Original	Replacement
VOL + TV Vol +	SHIFT + CH Shift + Ch +		
VOL - TV Vol -	SHIFT + CH Shift + Ch -		
TV/VIDEO TV/ Video	SEARCH TV/R TV/ R		