Original		Replacement	
	Power Tv		Power
	Av Tv	TIMER AV	AV
MENU	Menu Tv	TOP MENU MENU	Menu
	Up Tv		Up
	Down Tv		Down
	Left Tv		Left
	Right Tv		Right
OK	Ok Tv	OK	Ok
INFO	Info Tv	DISPLAY INFO	Info
EXIT	Exit Tv	CLEAR EXIT	Exit
	Red Tv	A	Red
	Green Tv	B	Green
	Yellow Tv	C	Yellow
	Blue Tv	D	Blue
+ VOL	Vol + Tv	+ VOL	Vol +
VOL −	Vol - Tv	VOL −	Vol -
	Mute Tv	MUTE	Mute

Original		Replacement	
P•P	Back Tv	RETURN BACK	Back
+ CH	Ch+ Tv	+ CH	Ch +
CH −	Ch- Tv	CH −	Ch -
▼P[≡]	▼P[≡] Tv		I <<
▲P[ ]	▲P[ ] Tv		>>I
	<< Tv		<<
	>> Tv		>>
	Stop Tv		Stop
	Play Tv	PLAY MODE	Play
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7
8	8 Tv	8	8

Original	Replacement
9 Tv	9
0 Tv	0
Text Tv	Text
#Help Tv	Pre Ch
▼P [≡] Tv2	Shift + I<<
▲P [ ] Tv2	Shift + >>I
Rec Tv2	Shift + Rec
Play Tv2	Shift + Play
Av Tv2	Shift + AV
<< Tv2	Shift + <<
>> Tv2	Shift + >>
Power Tv2	Shift + Power
Guide Tv2	Shift + Guide
Menu Tv2	Shift + Menu
Up Tv2	Shift + Up
Left Tv2	Shift + Left
Right Tv2	Shift + Right

Original	Replacement
Down Tv2	Shift + Down
Ok Tv2	Shift + Ok
Info Tv2	Shift + Info
Green Tv2	Shift + Green
Red Tv2	Shift + Red
Exit Tv2	Shift + Exit
Yellow Tv2	Shift + Yellow
Blue Tv2	Shift + Blue
Back Tv2	Shift + Back
Ch+ Tv2	Shift + Ch +
Ch- Tv2	Shift + Ch -
Stop Tv2	Shift + Stop
Pause Tv2	Shift + Pause
1 Tv2	Shift + 1
2 Tv2	Shift + 2
3 Tv2	Shift + 3
4 Tv2	Shift + 4

Original		Replacement		Original	Replacement
5	5 Tv2	SHIFT + 5	Shift + 5		
6	6 Tv2	SHIFT + 6	Shift + 6		
7	7 Tv2	SHIFT + 7	Shift + 7		
8	8 Tv2	SHIFT + 8	Shift + 8		
9	9 Tv2	SHIFT + 9	Shift + 9		
0	0 Tv2	SHIFT + 0	Shift + 0		
* TXT	Text Tv2	SHIFT + REPEAT TEXT	Shift + Text		
# HELP	#Help Tv2	SHIFT + FAV PRE-CH	Shift + Pre Ch		

Original	Replacement
Power DVD	Power
AV DVD/DVR	AV
Guide DVD/DVR	Guide
Menu DVD/DVR	Menu
Info DVD/DVR	Info
Exit DVD/DVR	Exit
Up DVD/DVR	Up
Down DVD/DVR	Down
Left DVD/DVR	Left
Right DVD/DVR	Right
Ok DVD/DVR	Ok
Red DVD/DVR	Red
Green DVD/DVR	Green
Yellow	Yellow
Blue DVD/DVR	Blue
Vol + DVD/DVR	Vol +
Vol - DVD/DVR	Vol -

Original	Replacement
Mute DVD/DVR	Mute
Back DVD/DVR	Back
Ch+ DVD/DVR	Ch +
▼P[≡] DVD/DVR	I <<
Ch- DVD/DVR	Ch -
▲P[ ] DVD/DVR	>>I
<< DVD/DVR	<<
>> DVD/DVR	>>
Play DVD/DVR	Play
Pause DVD/DVR	Pause
Stop DVD/DVR	Stop
Rec DVD/DVR	Rec
1 DVD/DVR	1
2 DVD/DVR	2
3 DVD/DVR	3
4 DVD/DVR	4
5 DVD/DVR	5

Original		Replacement		Original	Replacement
6	6 DVD/ DVR	6	6		
7	7 DVD/ DVR	7	7		
8	8 DVD/ DVR	8	8		
9	9 DVD/ DVR	9	9		
0	0 DVD/ DVR	0	0		
* TXT	Text DVD/ DVR	REPEAT TEXT	Text		
# HELP	#Help DVD/ DVR	FAV PRE-CH	Pre Ch		
	Power DVR	SHIFT +	Shift + Power		

Original		Replacement	
	Power		Power
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	GUIDE	Guide
AV	AV SAT/CABLE	TIMER AV	AV
	Up SAT/CABLE		Up
	Down		Down
	Left SAT/CABLE		Left
	Right		Right
OK	Ok SAT/CABLE	OK	Ok
INFO	Info SAT/CABLE	DISPLAY INFO	Info
EXIT	Exit SAT/CABLE	CLEAR EXIT	Exit
	Red SAT/CABLE	A	Red
	Green	B	Green
	Yellow SAT/CABLE	C	Yellow
	Blue SAT/CABLE	D	Blue
VOL +	Vol +	VOL +	Vol +
VOL −	Vol - SAT/CABLE	VOL −	Vol -

Original		Replacement	
	Mute	MUTE	Mute
P<P	Back	RETURN BACK	Back
CH +	Ch+ SAT/CABLE	CH +	Ch +
CH −	Ch- SAT/CABLE	CH −	Ch -
	<< SAT/CABLE		<<
	>> SAT/CABLE		>>
	Stop SAT/CABLE		Stop
	Rec SAT/CABLE	REC MODE	Rec
	Play SAT/CABLE	PLAY MODE	Play
	Pause		Pause
1	1 SAT/CABLE	1	1
2	2 SAT/CABLE	2	2
3	3 SAT/CABLE	3	3
4	4 SAT/CABLE	4	4
5	5 SAT/CABLE	5	5
6	6 SAT/CABLE	6	6
7	7 SAT/CABLE	7	7

Original		Replacement		Original	Replacement
8	8 SAT/ CABLE	8	8		
9	9 SAT/ CABLE	9	9		
0	0 SAT/ CABLE	0	0		
# HELP	#Help	FAV PRE-CH	Pre Ch		
* TXT	Text SAT/ CABLE	REPEAT TEXT	Text		

Original	Replacement	Original	Replacement
Power DVBT	Power	Ch+ DVBT	Ch +
Gui de DVBT	Gui de	Ch- DVBT	Ch -
Menu DVBT	Menu	Pause DVBT	Pause
Up DVBT	Up	1 DVBT	1
Down DVBT	Down	2 DVBT	2
Left DVBT	Left	3 DVBT	3
Ri ght DVBT	Ri ght	4 DVBT	4
Ok DVBT	Ok	5 DVBT	5
I nfo DVBT	I nfo	6 DVBT	6
Red DVBT	Red	7 DVBT	7
Gr een DVBT	Gr een	8 DVBT	8
Yel l ow DVBT	Yel l ow	9 DVBT	9
Bl ue DVBT	Bl ue	0 DVBT	0
Vol + DVBT	Vol +	Power VCR	Shi f t + Power
Vol - DVBT	Vol -	Av VCR	AV
Mut e DVBT	Mut e	<< VCR	<<
Back DVBT	Back	St op VCR	St op

Original	Replacement
>> VCR	>>
Play VCR	Play
Rec VCR	Rec
Pause VCR	Shift + Pause
Guide VCR	Shift + Guide
Menu VCR	Shift + Menu
Up VCR	Shift + Up
Down VCR	Shift + Down
Left VCR	Shift + Left
Right VCR	Shift + Right
Ok VCR	Shift + Ok
Info VCR	Shift + Info
Exit VCR	Exit
Red VCR	Shift + Red
Green VCR	Shift + Green
Yellow VCR	Shift + Yellow
Blue VCR	Shift + Blue

Original	Replacement
Back VCR	Shift + Back
Ch+ VCR	Shift + Ch +
Ch- VCR	Shift + Ch -
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
Text VCR	Text
#Help VCR	Pre Ch