| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| CBL/SAT | CBL/SAT | SHIFT + HDMI - SAT 0 | Shift + 0 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TV AUDIO | TV Audio | SHIFT + TV 1 | Shift + 1 |
| Blu-ray | Blu-ray | SHIFT + VIDEO 4 | Shift + 4 |
| AUX1 | AUX1 | SHIFT + AUX - HDD 7 | Shift + 7 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| GAME | Game | SHIFT + TAPE 5 | Shift + 5 |
| AUX2 | AUX2 | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| PHONO | Phono | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| iPod/USB | iPod/USB | SHIFT + USB 8 | Shift + 8 |
| MEDIA PLAYER | Media Player | -/-- GUIDE EPG | Guide / EPG / -/-- |
| CD | CD | SHIFT + CD - STB 3 | Shift + 3 |
| NETWORK | Network | SHIFT + BLUETOOTH 9 | Shift + 9 |
| INTERNET RADIO | Internet/Radio | PC FAV MARKER | Fav / Marker / PC |
| 1 | Favorite Station | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| FAVORITE 2 | Favorite Station | SHIFT + APP REPEAT | Shift + Green / APP / Repeat |

| Original | | Rechange | |
|---|---|---|---|
| STATION 3 | Favorite Station | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| 4 | Favorite Station | SHIFT + Prime Video RANDOM | Shift + Blue / Prime |
| CH/PAGE | CH/Page+ | CH PAGE | CH+ / Page+ |
| InstaPrevue | InstaPrevus | LIST SMART | Smart / List |
| VOLUME | Vol + | VOL | Vol + |
| CH/PAGE | CH/Page- | CH PAGE | CH- / Page- |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| | Vol - | VOL | Vol - |
| INFO | Info | ANGLE INFO | Info / Angle |
| | Up | | Up |
| OPTION | Option | SHIFT + OPT-TOOLS SETUP | Shift + Setup / OPT / Tools |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| BACK | Back | RETURN BACK | Back / Return |
| | Down | | Down |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / Tools |

| Original | | Rechange | | Original | | Rechange | |
|---|---|---|---|---|---|---|---|
| TUNE – | I <<  / Tune- | PRESET- | I <<  / Preset- | GHI 4 | 4 | VIDEO 4 | 4 |
| TUNE – | I <<  / Tune- | SHIFT + TUNE- | Shift + <<  / | JKL 5 | 5 | TAPE 5 | 5 |
| ▶ | Play | SLOW ▶ | Play / Slow | MNO 6 | 6 | TUNER 6 | 6 |
| TUNE + | >>I / Tune+ | PRESET+ | >>I / Preset+ | PQRS 7 | 7 | AUX - HDD 7 | 7 |
| TUNE + | >>I / Tune+ | SHIFT + TUNE+ | Shift + >>  / | TUV 8 | 8 | USB 8 | 8 |
| ◀◀ | << | TUNE- | << / Tune- | WXYZ 9 | 9 | BLUETOOTH 9 | 9 |
| ❚❚ | Pause | STEP - FREEZE ❚❚ | Pause / Step / Freeze | 0 | 0 | HDMI - SAT 0 | 0 |
| ■ | Stop | HOLD ■ | Stop / Hold | | | | |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ | | | | |
| MOVIE | Green/Movie | APP REPEAT | Green / APP / Repeat | | | | |
| SOUND MUSIC | Red/Music | NETFLIX SEARCH | Red / Netflix / Search | | | | |
| MODE GAME | Blue/Game | Prime Video RANDOM | Blue / Prime Video / Random | | | | |
| PURE | Yellow/Pure | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | | | |
| 1 | 1 | TV 1 | 1 | | | | |
| ABC 2 | 2 | DVD 2 | 2 | | | | |
| DEF 3 | 3 | CD - STB 3 | 3 | | | | |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer | | | | |

| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| CBL/SAT | CBL/SAT | SHIFT + HDMI - SAT 0 | Shift + 0 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TV AUDIO | TV Audio | SHIFT + TV 1 | Shift + 1 |
| Blu-ray | Blu-ray | SHIFT + VIDEO 4 | Shift + 4 |
| AUX1 | AUX1 | SHIFT + AUX - HDD 7 | Shift + 7 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| GAME | Game | SHIFT + TAPE 5 | Shift + 5 |
| AUX2 | AUX2 | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| PHONO | Phono | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| iPod/USB | iPod/USB | SHIFT + USB 8 | Shift + 8 |
| MEDIA PLAYER | Media Player | -/-- GUIDE EPG | Guide / EPG / -/-- |
| CD | CD | SHIFT + CD - STB 3 | Shift + 3 |
| NETWORK | Network | SHIFT + BLUETOOTH 9 | Shift + 9 |
| INTERNET RADIO | Internet/Radio | PC FAV MARKER | Fav / Marker / PC |
| 1 | Favorite Station | NETFLIX SEARCH | Red / Netflix / Search |
| FAVORITE 2 | Favorite Station | APP REPEAT | Green / APP / Repeat |

| Original | | Rechange | |
|---|---|---|---|
| STATION 3 | Favorite Station | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 4 | Favorite Station | Prime Video RANDOM | Blue / Prime Video / Random |
| CH/PAGE ▲ | CH/Page+ | CH PAGE + | CH+ / Page+ |
| VOLUME ▲ | Vol + | VOL + | Vol + |
| CH/PAGE ▼ | CH/Page- | CH PAGE – | CH- / Page- |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| ▼ | Vol - | VOL – | Vol - |
| ▲ | Up | ▲ | Up |
| ◄ | Left | ◄ | Left |
| ENTER | Enter | OK | OK |
| ► | Right | ► | Right |
| BACK | Back | RETURN BACK | Back / Return |
| ▼ | Down | ▼ | Down |
| TUNE – | I<</Tune- | PRESET- | I<< / Preset- |
| TUNE – | I<</Tune- | SHIFT + TUNE- | Shift + <</ |
| ► | Play | SLOW ▶ | Play / Slow |
| TUNE + | >>I/Tune+ | PRESET+ | >>I / Preset+ |

| Original | Rechange | Original | Rechange |
|---|---|---|---|
| >>I / Tune+ | Shift + >> / | | |
| << | << / Tune- | | |
| Pause | Pause / Step / Freeze | | |
| Stop | Stop / Hold | | |
| >> | >> / Tune+ | | |
| 1 | 1 | | |
| 2 | 2 | | |
| 3 | 3 | | |
| Sleep | Sleep / Timer | | |
| 4 | 4 | | |
| 5 | 5 | | |
| 6 | 6 | | |
| 7 | 7 | | |
| 8 | 8 | | |
| 9 | 9 | | |
| 0 | 0 | | |

| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | | Power |
| CBL/SAT | CBL/SAT | SHIFT + HDMI - SAT 0 | Shift + 0 |
| DVD | DVD | SHIFT + DVD 2 | Shift + 2 |
| TV AUDIO | Tv Audio | SHIFT + TV 1 | Shift + 1 |
| Blu-ray | Blu-ray | SHIFT + VIDEO 4 | Shift + 4 |
| AUX1 | AUX1 | SHIFT + AUX - HDD 7 | Shift + 7 |
| TUNER | Tuner | SHIFT + TUNER 6 | Shift + 6 |
| GAME | Game | SHIFT + TAPE 5 | Shift + 5 |
| AUX2 | AUX2 | SHIFT + -/-- GUIDE EPG | Shift + Guide / EPG / -/-- |
| PHONO | Phono | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| iPod/USB | iPod/USB | SHIFT + USB 8 | Shift + 8 |
| MEDIA PLAYER | Media Player | -/-- GUIDE EPG | Guide / EPG / -/-- |
| CD | CD | SHIFT + CD - STB 3 | Shift + 3 |
| NETWORK | Network | SHIFT + BLUETOOTH 9 | Shift + 9 |
| INTERNET RADIO | Internet/Radio | PC FAV MARKER | Fav / Marker / PC |
| 1 | Favorite Station | NETFLIX SEARCH | Red / Netflix / Search |
| FAVORITE 2 | Favorite Station | APP REPEAT | Green / APP / Repeat |

| Original | | Rechange | |
|---|---|---|---|
| STATION 3 | Favorite Station | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| 4 | Favorite Station | Prime Video RANDOM | Blue / Prime Video / Random |
| CH/PAGE | CH/Page+ | CH PAGE | CH+ / Page+ |
| VOLUME | Vol + | VOL | Vol + |
| CH/PAGE | CH/Page- | CH PAGE | CH- / Page- |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| | Vol - | VOL | Vol - |
| | Up | | Up |
| | Left | | Left |
| ENTER | Enter | OK | OK |
| | Right | | Right |
| BACK | Back | RETURN BACK | Back / Return |
| | Down | | Down |
| TUNE – | I<</Tune- | PRESET- | I<< / Preset- |
| TUNE – | I<</Tune- | SHIFT + TUNE- | Shift + <</ |
| | Play | SLOW | Play / Slow |
| TUNE + | >>I/Tune+ | PRESET+ | >>I / Preset+ |

| Original | | Rechange | | Original | | Rechange |
|---|---|---|---|---|---|---|
| TUNE + | >>I / Tune+ | SHIFT + TUNE+ | Shift + >> / | | | |
| | << | TUNE- | << / Tune- | | | |
| | Pause | STEP-FREEZE | Pause / Step / Freeze | | | |
| | Stop | HOLD | Stop / Hold | | | |
| | >> | TUNE+ | >> / Tune+ | | | |
| 1 | 1 | TV 1 | 1 | | | |
| ABC 2 | 2 | DVD 2 | 2 | | | |
| DEF 3 | 3 | CD-STB 3 | 3 | | | |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer | | | |
| GHI 4 | 4 | VIDEO 4 | 4 | | | |
| JKL 5 | 5 | TAPE 5 | 5 | | | |
| MNO 6 | 6 | TUNER 6 | 6 | | | |
| PQRS 7 | 7 | AUX-HDD 7 | 7 | | | |
| TUV 8 | 8 | USB 8 | 8 | | | |
| WXYZ 9 | 9 | BLUETOOTH 9 | 9 | | | |
| 0 | 0 | HDMI-SAT 0 | 0 | | | |