Original		Rechange	
MENU/PBC	PBC	TOP MENU D.MENU	D. Menu / Top
LANGUAGE	Audio	LANG I/II AUDIO	Audio / Lang I/II
STANDBY	Power		Power
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Open / Close	SURROUND	Eject / Surround
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
ANGLE	Angle	ANGLE INFO	Info / Angle
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
P/N	Pal / NTSC	FORMAT PICTURE	Picture / Format

Original		Rechange	
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
DISPLAY	Display	MEDIA DISPLAY	Display / Media
PROG	Program	PROGRAM TV/RADIO	TV/Radio /
A-B	Repeat A-B	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
SLOW	Slow	SHIFT + SLOW	Shift + Play /
GOTO	Goto	GOTO TEXT	Text / Goto
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I<<	PRESET-	I<< / Preset-
	>>I	PRESET+	>>I / Preset+
MENU/PBC	Menu	HOME MENU	Menu / Home
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right

Original		Rechange		Original		Rechange
STOP	Stop	HOLD	Stop / Hold			
	Down		Down			
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze			
PLAY	Play	SLOW	Play / Slow			

Original		Rechange	
STANDBY	Power		Power
	Video SW	HOME MENU	Menu / Home
	Video / PScan	TOP MENU D.MENU	D.Menu / Top
	Open / Close	SURROUND	Eject / Surround
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
LANGUAGE	Language	LANG I/II AUDIO	Audio / Lang I/II
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
ANGLE	Angle	ANGLE INFO	Info / Angle
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
P/N	N/P	PC FAV MARKER	Fav / Marker / PC

Original		Rechange	
10	0	HDMI-SAT 0	0
10+	10+	-/-- GUIDE EPG	Guide / EPG / -/--
GOTO	Goto	GOTO TEXT	Text / Goto
TITLE	Title	TITLE SOUND	Sound / Title
PROG	Prog	PROGRAM TV/RADIO	TV/Radio /
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
DISPLAY	OSD	MEDIA DISPLAY	Display / Media
SLOW	Slow	SHIFT + SLOW ▶	Shift + Play /
	Step	STEP-FREEZE ⏸	Pause / Step / Freeze
A-B	AB	YouTube REPEAT A-B	Yellow / YouTube / Repeat
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
◀◀	<<	TUNE- ◀◀	<< / Tune-
▶▶	>>	TUNE+ ▶▶	>> / Tune+
⏮	I<<	PRESET- ⏮	I<< / Preset-
⏭	>>I	PRESET+ ⏭	>>I / Preset+
MENU/PBC	PBC	LIST SMART	Smart / List
ZOOM	Zoom	SIZE ZOOM	Zoom / Size

Original		Rechange	
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Root	NETFLIX SEARCH	Red / Netflix / Search
	Down		Down
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STOP	Stop	HOLD	Stop / Hold
PLAY	Play / Pause	SLOW	Play / Slow
VOL -	Vol -	VOL -	Vol -
VOL +	Vol +	VOL +	Vol +

Original	Rechange