Original	Rechange	Original	Rechange
Power	Power	Right	Right
Mute	Mute / Dimmer	Down	Down
Play	Play / Slow	Vol +	Vol +
Stop	Stop / Hold	[-O-] / Active Control	Smart / List
Rec	Rec / Rec Mode	P+	CH+ / Page+
<<	<< / Tune-	Vol -	Vol -
>>	>> / Tune+	P-	CH- / Page-
[<>]	Picture / Format	1	1
>I<	D.Menu / Top	2	2
[1I2]	Setup / OPT /	3	3
[≡]	Text / Goto	4	4
Source	AV / Input / RDS	5	5
Menu	Menu / Home	6	6
Up	Up	7	7
[i+]	Info / Angle	8	8
Left	Left	9	9
OK	OK	Guide	Guide / EPG / -/--

Original	Rechange
0	0
P<P	Fav / Marker / PC
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Power AMP	Shift + Power
Mute AMP	Shift + Mute / Dimmer
<< AMP	Shift + << /
>> AMP	Shift + >> /
[≡] AMP	Shift + Text /
Menu AMP	Shift + Menu /
Up AMP	Shift + Up
Left AMP	Shift + Left
OK AMP	Shift + OK
Right AMP	Shift + Right
Down AMP	Shift + Down

Original	Rechange
Vol + AMP	Shift + Vol +
P+ AMP	Shift + CH+ /
Vol - AMP	Shift + Vol -
P- AMP	Shift + CH- /
1 AMP	Shift + 1
2 AMP	Shift + 2
3 AMP	Shift + 3
4 AMP	Shift + 4
5 AMP	Shift + 5
6 AMP	Shift + 6
7 AMP	Shift + 7
8 AMP	Shift + 8
9 AMP	Shift + 9
Guide AMP	Shift + Guide / EPG / -/--
0 AMP	Shift + 0
P<P AMP	Shift + Fav / Marker / PC

Original	Rechange	Original	Rechange
Power	Power	P-	CH- / Page-
Guide	Guide / EPG / -/--	1	1
Source	AV / Input / RDS	2	2
>I<	D.Menu / Top	3	3
[1I2]	Setup / OPT /	4	4
[i+]	Info / Angle	5	5
Up	Up	6	6
Left	Left	7	7
OK	OK	8	8
Right	Right	9	9
Down	Down	0	0
[≡]	Text / Goto	P<P	Fav / Marker / PC
Menu	Menu / Home	<<	<< / Tune-
Vol +	Vol +	Stop	Stop / Hold
Mute	Mute / Dimmer	Play	Play / Slow
P+	CH+ / Page+	>>	>> / Tune+
Vol -	Vol -	[<>]	Picture / Format

Original	Rechange	Original	Rechange
[-O-]/Active Control	Smart / List		

Original		Rechange		Original		Rechange	
	Power		Power		Down		Down
	Mute	DIMMER MUTE	Mute / Dimmer	+ VOL	Vol +	+ VOL	Vol +
	Play	SLOW ▶	Play / Slow	DIGITAL SET UP	[-O-] / Active Control	LIST SMART	Smart / List
INSTANT	Stop	HOLD ■	Stop / Hold	+ CH	P+	+ CH PAGE	CH+ / Page+
INSTANT	Rec	REC MODE ●	Rec / Rec Mode	VOL −	Vol -	VOL −	Vol -
	<<	TUNE- ◀◀	<< / Tune-	CH −	P-	CH PAGE −	CH- / Page-
	>>	TUNE+ ▶▶	>> / Tune+	1	1	TV 1	1
	[<>]	FORMAT PICTURE	Picture / Format	2	2	DVD 2	2
P/P FREEZE	>I<	TOP MENU D.MENU	D.Menu / Top	3	3	CD - STB 3	3
MULTI PIP	[1I2]	OPT-TOOLS SETUP	Setup / OPT /	4	4	VIDEO 4	4
	Source	RDS AV INPUT	AV / Input / RDS	5	5	TAPE 5	5
MENU	Menu	HOME MENU	Menu / Home	6	6	TUNER 6	6
	Up	▲	Up	7	7	AUX - HDD 7	7
HOME CINEMA	[i+]	ANGLE INFO	Info / Angle	8	8	USB 8	8
	Left	◀	Left	9	9	BLUETOOTH 9	9
OK	OK	OK	OK	0	0	HDMI - SAT 0	0
	Right	▶	Right	P<P	P<P	PC FAV MARKER	Fav / Marker / PC

Original	Rechange
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Power VCR	Shift + Power
Play VCR	Shift + Play /
Stop VCR	Shift + Stop /
Rec VCR	Shift + Rec / Rec Mode
<< VCR	Shift + << /
>> VCR	Shift + >> /
>I < VCR	Shift + D.Menu / Top Menu
Source VCR	Shift + AV / Input / RDS
Menu VCR	Shift + Menu /
Up VCR	Shift + Up
[i+] VCR	Shift + Info / Angle
Left VCR	Shift + Left
OK VCR	Shift + OK

Original	Rechange
Right VCR	Shift + Right
Down VCR	Shift + Down
P+ VCR	Shift + CH+ /
P- VCR	Shift + CH- /
1 VCR	Shift + 1
2 VCR	Shift + 2
3 VCR	Shift + 3
4 VCR	Shift + 4
5 VCR	Shift + 5
6 VCR	Shift + 6
7 VCR	Shift + 7
8 VCR	Shift + 8
9 VCR	Shift + 9
0 VCR	Shift + 0
P<P VCR	Shift + Fav / Marker / PC

Original		Rechange	
	Power		Power
	Guide	GUIDE EPG	Guide / EPG / -/--
	>I<	TOP MENU D.MENU	D.Menu / Top
	[i+]	ANGLE INFO	Info / Angle
	Up		Up
	Left		Left
	Right		Right
	Down		Down
	Vol +	VOL +	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
	P+	CH PAGE +	CH+ / Page+
	Vol -	VOL -	Vol -
	P-	CH PAGE -	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4

Original		Rechange	
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
P<P	P<P	PC FAV MARKER	Fav / Marker / PC
<<	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
>>	>>	TUNE+	>> / Tune+