# Mandis shop

RC4870

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Menu | Menu / Home |
| Mute | Mute / Dimmer | Up | Up |
| Play | Play / Slow | i | Info / Angle |
| Pause | Pause / Step / Freeze | Left | Left |
| Stop | Stop / Hold | OK | OK |
| Rec | Rec / Rec Mode | Right | Right |
| << | << / Tune- | Exit | Exit / Cancel / Clear |
| >> | >> / Tune+ | Down | Down |
| Lang | Audio / Lang I/II | Back | Back / Return |
| Source (Games) | Eject / Surround | Vol + | Vol + |
| Movie-Music-Phot | Picture / Format | World (Violet) | Smart / List |
| [≡]. . | Zoom / Size | PR+ | CH+ / Page+ |
| */O | Sleep / Timer | Vol - | Vol - |
| TV | TV/Radio / | */Q | Display / Media |
| Q. Menu | D. Menu / Top | PR- | CH- / Page- |
| [-O-] | Setup / OPT / | 1 | 1 |
| [≡]/Text | Text / Goto | 2 | 2 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 3def | 3 | CD-STB 3 | 3 | | |
| 4ghi | 4 | VIDEO 4 | 4 | | |
| 5jkl | 5 | TAPE 5 | 5 | | |
| 6mno | 6 | TUNER 6 | 6 | | |
| 7pqrs | 7 | AUX-HDD 7 | 7 | | |
| 8tuv | 8 | USB 8 | 8 | | |
| 9wxyz | 9 | BLUETOOTH 9 | 9 | | |
| | Guide | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| 0 | 0 | HDMI-SAT 0 | 0 | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| | Recall | SHIFT + | RETURN BACK Shift + Back / Return | | |
| | | | | | |
| | | | | | |
| | | | | | |