Original		Replacement	
	Power		Power
	Netflix	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2 abc	2	DVD 2	2
3 def	3	CD - STB 3	3
4 ghi	4	VIDEO 4	4
5 jkl	5	TAPE 5	5
6 mno	6	TUNER 6	6
7 pqrs	7	AUX - HDD 7	7
8 tuv	8	USB 8	8
9 wxyz	9	BLUETOOTH 9	9
	TV	SHIFT + TV 1	Shift + 1
	TV	PROGRAM TV/ RADIO	TV/ Radio /
0	0	HDMI - SAT 0	0
	↔	PC FAV MARKER	Fav / Marker / PC
+ V	Vol +	+ VOL	Vol +

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	+ CH PAGE	CH+ / Page+
V	Vol -	VOL −	Vol -
	Internet	LIST SMART	Smart / List
P	P-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
	Up		Up
Q.MENU	Q. Menu	TOP MENU D.MENU	D. Menu / Top
	Left		Left
OK	OK	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
i	i	ANGLE INFO	Info / Angle
	[>]	MEDIA DISPLAY	Display / Media
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Replacement	Original	Replacement
*/o	SHIFT + SMART (LIST) — Shift + Smart / List		
*/Q	SHIFT + DISPLAY (MEDIA) — Shift + Display / Media		
TXT	TEXT (GOTO) — Text / Goto		
Red	NETFLIX (SEARCH) — Red / Netflix / Search		
Green	APP (REPEAT) — Green / APP / Repeat		
Yellow	YouTube (REPEAT A-B) — Yellow / YouTube / Repeat		
Blue	Prime Video (RANDOM) — Blue / Prime Video / Random		
Lang	AUDIO (LANG I/II) — Audio / Lang I/II		
Subt.	SUBTITLE (EQ) — Subtitle / EQ		
←[+]→	PICTURE (FORMAT) — Picture / Format		
<<	<< (TUNE-) — << / Tune-		
Pause	II (STEP-FREEZE) — Pause / Step / Freeze		
>>	>> (TUNE+) — >> / Tune+		
Rec	REC MODE — Rec / Rec Mode		
Play	▶ (SLOW) — Play / Slow		
Stop	■ (HOLD) — Stop / Hold		