Original		Replacement		Original		Replacement	
TEXT	Text	GOTO TEXT	Text / Goto	▼	Down	▼	Down
POWER	Power	⏻	Power	INFO	Info	ANGLE INFO	Info / Angle
	Red	NETFLIX SEARCH	Red / Netflix / Search	+ VOL	Vol +	+ VOL	Vol +
	Green	APP REPEAT	Green / APP / Repeat	▶/II	Play	SLOW ▶	Play / Slow
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat	▶/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
	Blue	Prime Video RANDOM	Blue / Prime Video / Random	+ CH	CH+	+ CH PAGE	CH+ / Page+
TV/♪	Tv/♪	PROGRAM TV/RADIO	TV/Radio /	VOL −	Vol -	VOL −	Vol -
MENU	Menu	HOME MENU	Menu / Home	🔇	Mute	DIMMER MUTE	Mute / Dimmer
APP	APP	SHIFT + APP REPEAT	Shift + Green / APP /	CH −	CH-	CH PAGE −	CH- / Page-
DISP	Disp	MEDIA DISPLAY	Display / Media	1 @%"	1	TV 1	1
BACK	Back	RETURN BACK	Back / Return	2 ABC	2	DVD 2	2
▲	Up	▲	Up	3 DEF	3	CD-STB 3	3
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear	4 GHI	4	VIDEO 4	4
◀	Left	◀	Left	5 JKL	5	TAPE 5	5
OK	OK	OK	OK	6 MNO	6	TUNER 6	6
▶	Right	▶	Right	7 PQRS	7	AUX-HDD 7	7
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--	8 TUV	8	USB 8	8

Original		Replacement	
9 WXYZ	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
OPT	Opt.	OPT-TOOLS SETUP	Setup / OPT /

Original	Replacement