Mandis shop

ICUBE790

Original		Replacement	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
MOVIE	Movie	PROGRAM TV/ RADIO	TV/Radio /
PHOTO	Photo	LIST SMART	Smart / List
MUSIC	Music	TITLE SOUND	Sound / Title
BROWSER	Browser	MEDIA DISPLAY	Display / Media
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
INFO	Info	ANGLE INFO	Info / Angle
FF	>>/FF	TUNE+	>> / Tune+
NEXT	>>I/Next	PRESET+	>>I / Preset+
VOL+	Vol+	VOL +	Vol+
FR	<<FR	TUNE-	<< / Tune-
PREV	I<<Prev	PRESET-	I<< / Preset-
VOL–	Vol-	VOL –	Vol-
HOME	Home	HOME MENU	Menu / Home
	Up		Up
RETURN	Return	RETURN BACK	Back / Return

Original		Replacement	
	Left		Left
	Enter	OK	OK
	Right		Right
PLAY PAUSE	Play	SLOW	Play / Slow
PLAY PAUSE	Pause	STEP - FREEZE	Pause / Step / Freeze
	Down		Down
STOP	Stop	HOLD	Stop / Hold
GOTO	Goto	GOTO TEXT	Text / Goto
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
ROTATE	Rotate	PC FAV MARKER	Fav / Marker / PC
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SUB-T	Sub-T	EQ SUBTITLE	Subtitle / EQ
16:9	16:9	FORMAT PICTURE	Picture / Format
AV	AV	RDS AV INPUT	AV / Input / RDS
HDMI	HDMI	HDMI - SAT 0	0

https://telecommandes-mandis.be/en/Woxter/1039040-65520-replacement-remote-control-for-Woxter-ICube790.html