Original	Replacement
Mute	Mute / Dimmer
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
S	Setup / OPT /
0	0
Source	AV / Input / RDS
Menu/Menu	Menu / Home
Guide	Guide / EPG / -/--
Tv/Fav/Radio	TV/Radio / Program

Original	Replacement
Exit/Back	Exit / Cancel / Clear
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
PR+	CH+ / Page+
Vol -	Vol -
Vol +	Vol +
PR-	CH- / Page-
[++]	Smart / List
→I [/] I ←	Display / Media
[i +]	Info / Angle
Text	Text / Goto
I I >/ [▼]	Shift + >> /
Play/O) I / I I	Play / Slow
<<I [≡o]	<< / Tune-

Original		Replacement		Original	Replacement
SUBTITLE	>>/ Subtitle	TUNE+	>> / Tune+		
	Open/close/[≡?]	SURROUND	Eject / Surround		
	Stop/[≡+]	HOLD	Stop / Hold		
	I<<</[≡↕]	PRESET-	I<< / Preset-		
	>>I/[≡x]/[O]	PRESET+	>>I / Preset+		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		

Original	Replacement
Mute	Mute / Dimmer
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Menu/DVD	Menu / Home
Exit/Back	Exit / Cancel / Clear
Up	Up
Left	Left
OK	OK

Original	Replacement
Right	Right
Down	Down
Vol -	Vol -
Vol +	Vol +
▮▮/▮▮▶ / [▼]	Pause / Step / Freeze
▶ / I/II	Shift + Play /
▶ / I/II	Play / Slow
◀◀ / [≡◀]	<< / Tune-
◀◀ / [≡◀]	Shift + << /
▶▶ / Subtitle	Shift + >> /
▶▶ / Subtitle	>> / Tune+
▲	Eject / Surround
■ / [≡□]	Stop / Hold
▮◀◀ / [≡↕]	I<< / Preset-
▮◀◀ / [≡↕]	Shift + I<< / Preset-
▶▶▮ / [◷][≡X]	Shift + >>I / Preset+
▶▶▮ / [◷][≡X]	>>I / Preset+

Original		Replacement	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	– 7	AUX-HDD 7	7
8	– 8	USB 8	8
9	– 9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
	Source	RDS AV INPUT	AV / Input / RDS
	P+	CH PAGE +	CH+ / Page+
	Vol -	VOL –	Vol -
	Vol +	VOL +	Vol +
	P-	CH PAGE –	CH- / Page-

Original		Replacement	
	▮▮/▮▮▶ / [▼]	STEP-FREEZE ▮▮	Pause / Step / Freeze
	▶ / I/II	SHIFT + SLOW ▶	Shift + Play /
	▶ / I/II	SLOW ▶	Play / Slow
	◀◀ / [≡●]	TUNE- ◀◀	<< / Tune-
	◀◀ / [≡●]	SHIFT + TUNE- ◀◀	Shift + << /
SUBTITLE	▶▶ / Subtitle	SHIFT + TUNE+ ▶▶	Shift + >> /
SUBTITLE	▶▶ / Subtitle	TUNE+ ▶▶	>> / Tune+
	▲	SURROUND ⏏	Eject / Surround
	■ / [≡□]	HOLD ■	Stop / Hold
	▮◀◀ / [≡↕]	SHIFT + PRESET- ▮◀◀	Shift + I<< / Preset-
	▮◀◀ / [≡↕]	PRESET- ▮◀◀	I<< / Preset-
	▶▶▮ / [◷][≡X]	SHIFT + PRESET+ ▶▶▮	Shift + >>I / Preset+
	▶▶▮ / [◷][≡X]	PRESET+ ▶▶▮	>>I / Preset+