Original		Replacement	
	Power		Power
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
	Recall	SHIFT + RETURN BACK	Shift + Back / Return
	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	+ CH PAGE	CH+ / Page+

Original		Replacement	
	Vol -	VOL −	Vol -
P	P-	CH PAGE −	CH- / Page-
MENU	Menu	HOME MENU	Menu / Home
QUICK	Quick	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
BACK	Back	RETURN BACK	Back / Return
	Down		Down
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	[i+]	ANGLE INFO	Info / Angle
	[>]	SHIFT +	Shift + Right
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	✱/O	OPT-TOOLS SETUP	Setup / OPT /
	✱/Q	SHIFT + OPT-TOOLS SETUP	Shift + Setup / OPT / Tools
TEXT	Text	GOTO TEXT	Text / Goto

Original		Replacement		Original	Replacement
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
I/II	O)I/II	LANG I/II AUDIO	Audio / Lang I/II		
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ		
	[++]	MEDIA DISPLAY	Display / Media		
<<	<<	TUNE- <<	<< / Tune-		
II	Pause	STEP-FREEZE II	Pause / Step / Freeze		
>>	>>	TUNE+ >>	>> / Tune+		
REC	Rec	REC MODE	Rec / Rec Mode		
▶	Play	SLOW ▶	Play / Slow		
■	Stop	HOLD ■	Stop / Hold		