Mandis shop

EN1020

Original	Replacement	Original	Replacement
Power	Power	Left	Left
Mute	Mute	OK	Ok
Red	Red	1	1
Green	Green	2	2
Yellow	Yellow	3	3
Blue	Blue	4	4
Vol +	Vol +	5	5
Vol -	Vol -	6	6
TXT	Text	7	7
Subt.	Subt	8	8
Menu	Menu	9	9
Home	Smart	0	0
EPG	Guide	Audio	Dual
Back	Back	DVB	TV/R
Up	Up		
Down	Down		
Right	Right		

https://telecomandi.shop/en/Engel/1553-853-replacement-remote-control-for-Engel-EN1020.html