Mandis shop

Philips 996510061053- DISC- USB DVD

Original		Replacement	
STANDBY	Standby		Power
EJECT	Eject	FAV 2. P/C	P/C / FAV
	Home	VOD	VOD
DISC/USB	Disc/USB	SRC	SRC
FM/AUX	FM/AUX	TV/R	TV/R
SUBTITLE/PRESET +	Up/Subtitle/Pres		UP
AUDIO/PRESET –	Down/Audio/Prese		DOWN
	Right		RIGHT
	Left		LEFT
OK	OK	OK	OK
	Back	BACK	BACK
SOUND	Sound		Audio
+	Vol +	+ VOL	VOL +
–	Vol -	VOL –	VOL -
	Mute		MUTE
	I<		First
	Play		Play

Original		Replacement	
	Pause		Pause
	Stop		Stop
	>I		Last
	>>		Fast Forward
	<<		Rewind
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
MENU	Menu	MENU	MENU
DISPLAY	Display	INFO	INFO

Original		Replacement	
OPTION	Option	OPT+	OPT+
PROG CLOCK SET	Prog/Clock Set	MEDIA	MEDIA
TIME SLEEP	Time/Sleep	EXIT	EXIT

Original	Replacement

Original		Replacement	
STANDBY	Standby		Power
FM/AUX	FM/AUX	TV/R	TV/R
SUBTITLE/PRESET+	Up/Subtitle/Pres	▲	UP
AUDIO/PRESET –	Down/Audio/Prese	▼	DOWN
	Right	▶	RIGHT
	Left	◀	LEFT
OK	OK	OK	OK
▶▶	>>	▶▶	Fast Forward
◀◀	<<	◀◀	Rewind
1	1	1	1
2	2	2 ABC	2
3	3	3 DEF	3
4	4	4 GHI	4
5	5	5 JKL	5
6	6	6 MNO	6
7	7	7 PQRS	7
8	8	8 TUV	8

Original		Replacement	
9	9	9 WXYZ	9
0	0	0	0
PROG CLOCK SET	Prog/Clock Set	MEDIA	MEDIA
DISC/USB	Disc/USB	SRC	SRC